

The Beltpack



1. **Battery**
2. **Increase Volume button (▲)**
3. **Decrease Volume button (▼)**
4. **PWR (Power) button**
5. **Headset cable connector**
6. **Battery-release latch**
7. **Power/Mode lights**
8. **Channel A (Intercom 1) button** - Includes 2-wire and 4-wire connections
9. **ISO (Isolate) button** - To All Wireless Headsets and Beltpacks, Base, ISO Relay and AUX OUT (if activated)
10. **Channel B (Intercom 2) button** - Includes 2-wire and 4-wire connections

Beltpack Setup



- Insert a fully charged battery in each Beltpack with the metal contacts inserted first. Slide it in until it snaps.
- NOTE:** The battery will not slide in if inserted incorrectly. Excessive force should not be necessary.
- Plug the Beltpack's headset cable connector into each Beltpack.

BP410 Beltpack Settings

To Set:	All functions are from an off state. Press the Power button and release with the appropriate buttons below.
ISO restrict On	A button
ISO restrict Off	A button and ISO buttons
Handsfree On selected button(s)	A button and/or B button and/or ISO and Volume up button (▲)
Handsfree Off selected button(s)	A button and/or B button and/or ISO and Volume down button (▼)
Listen-Only mode On	Volume down button (▼)
Listen-Only mode Off	Volume up button (▲)

To Set:	With the power already on...
Increase mic gain (15 steps)	Press the B button while repeatedly pressing the Volume up button (▲)
Decrease mic gain (15 steps)	Press the B button while repeatedly pressing the Volume down button (▼)
Increase sidetone level (5 steps)	Press the A button while repeatedly pressing the Volume up button (▲)
Decrease sidetone level (5 steps)	Press the A button while repeatedly pressing the Volume down button (▼)

General Use

Beltpack Sidetone Adjustment:

- Press and hold the **A button** while you repeatedly press up (▲) to increase or press down (▼) to decrease audio levels.

Changing the battery:

- When a Beltpack battery becomes weak, a headset voice prompt will say “Change battery.”
- Press the **RELEASE BATTERY button** on the belt clip of the pouch, and use your thumb to slide the battery from the belt-pac.
- When charging the battery using the AC50 Battery Charger, the charging time is about 2.5 hours.

The DX410 Console



Register Beltpack

- Make certain the Beltpack is turned Off.
- Press **REG button** on base station.
 - STATUS display on the base station shows “o” for registration mode.
- On the Beltpack, press and hold **ISO** while pressing **POWER** and then release all buttons.
 - The power lights blink red, then green and then turn off. One power light remains green.
 - The registration number will appear on the base station STATUS display.



AUTO NULL Adjustment (only if using 2-wire interface)

If echo is heard in wireless Beltpacks on A or B:

- Use pointed object (e.g. pen) to press and hold the A or B **AUTO NULL button** for 2 seconds.
 - CAUTION:** Before pressing an **AUTO NULL button**, be certain there are no open microphones on the wired system. Notify wired system users that a loud noise may occur in their headsets during the auto null adjustment.

The system may be out of operation for approximately 50 seconds during this adjustment.

Local Headset Communication

- **SEL button** selects communication with **A, B** or **ISO**.
 - **A, B** or **ISO** lights indicate selection.
- **TALK button**
 - Press and release quickly to “latch on” for open communication.
 - Press and hold while talking for momentary communication – release when finished.
- **VOLUME** control adjusts the audio level in local headset ear piece.
- **MIC LEVEL** control adjusts the audio level going out from local headset microphone.

Technical Support

In The Americas and Asia – Tel: +1.510.337.6600 or 1.800.462.4357 Menu option 1 • Hours: 8:00am-5:00pm Pacific Time • Web: www.clearcom.com
In Europe, Middle East and Africa – Tel: +44.1223.815000 • Hours: 8:00am-5:00pm GMT • Email: SalesSupportUS@clearcom.com