


# **ZOOM Nitro® Drive-Thru Timer System**

# Quick Start Guide

## **ZOOM Nitro Drive-Thru Timer Overview**

Measures drive-thru lane events for comparison to your service time goals at up to eight detection points in the drive-thru lane. The Dashboard displayed below provides an example overview for a single-lane drive-thru with seven lane detectors (PRE-MENU, MENU 1, CASHIER, SERVICE, and three Pull-Forward detectors) as well as two independent detectors (Mobile Pickup).



A green car or value like this 10:29 indicates you are exceeding your goal.

A yellow car or value like this **2:01** indicates you are meeting your goal.

A red car or value like this 10.32 indicates you are not meeting your goal.

to monitor the area before

the Pre-Menu for Drive Offs along with other en-

hanced metrics.


### **How to make changes to your ZOOM Nitro Timer**

1. To edit your Dashboard, use a mouse connected to the USB port on the CU or use a back-office PC if configured on the same network. Click on to open screen below.

The default language is English. Click on Canadian flag for French.

**Dashboard Layout**Click to open pane and select your desired layout.

- 2. Click on the **SECURITY**
- 3. Log in to the system.
  Note: The manager
  assigns permissions and
  passwords. If you do not
  have a password, contact
  HME Technical Support
  at the number below
  to obtain a temporary
  Manager password.
- Once logged in, click on DASHBOARD SETTINGS in the sidebar menu to edit.



Lane and Data Section Graphics Click on a graphical element on the Dashboard to open it for editing.

In this example, use the fields or toggles under the **Section Settings** to edit what is displayed.

Drive Offs and Pre-Menu Stack are enabled and therefore displayed here on the Dashboard (also see page 1 image).

## **Drive-Thru Leaderboard®**

The Drive-Thru Leaderboard shows the top three and bottom three stores ranked against others in your network. Your store will be outlined and displayed with its closest competitors.

### **Top 3 Stores**

Top 3 performing stores in your network.

#### Your Store

Your store will always be outlined and displayed with its closest competitors.



Also, visit the **HME Training Portal** at:

https://www.hme.com/training



## **Your System**

### **Timer Signal Processor (TSP)**

Receives event data from car detections in a drive-thru lane or reserved parking location.



TSP Mounted location:

**Control Unit (CU)** Receives and processes data from the TSP to provide information for the ZOOM Dashboard display.



CU Mounted location: \_

## Need more help?



A copy of this guide and more information can be found by scanning this QR code above. When you land on the web page, navigate to Drive-Thru Timer Systems and click/tap on ZOOM Nitro to expand. Or go to: https://www.hme.com/qsr/drive-thru-user-manuals

Need help? Call **1-800-848-4468**, options **1,2,3** or email us at **support@hme.com** 

#### HME, INC.

2848 Whiptail Loop, Carlsbad, CA 92010 USA Fax: 858-552-0172 | www.hme.com