



NEXEO | HDX™

Crew Communication Platform

Installation Guide

REGULATORY AND SAFETY

FCC CERTIFICATION AND MORE:

Regulatory and Compliance information can be found online by going to Drive-Thru Headset Systems>NEXEO | HDX at: <https://www.hme.com/qsr/drive-thru-user-manuals/>

ESD HANDLING INSTRUCTIONS



CAUTION: Contains parts and assemblies susceptible to damage by Electrostatic Discharge (ESD). This device is sensitive to electrostatic discharge and should be installed by personnel trained in ESD awareness. Proper handling procedures include wearing anti-static wrist straps.

SAFETY NOTICE



CAUTION: Wear proper eye, ear, and body protection when grinding, drilling or working with tools. Follow the manufacturer's safety information and operational instructions for tools and materials. Be aware of your surroundings. Failure to heed such precautions can cause injury and/or property damage.

HYGIENE, HEALTH, AND SAFETY

Part of this installation requires working within a restaurant/store where food is prepared and customers dine. Please consult the restaurant/store manager, standard operating procedures and any additional restaurant safety/advisory protocols available before beginning work within the restaurant/store. Follow the instructions and guidelines provided.

BATTERY DISPOSAL



HME cares about the environment. Please consult the laws and regulations within your municipality regarding the proper disposal of expired or dead batteries.

DISCLAIMER

HM Electronics, Inc. is not responsible for equipment malfunctions due to erroneous translation of its publications from their original English version. Illustrations in this publication are approximate representations of the actual equipment, and may not be exactly as the equipment appears. They are subject to change without notice.

TABLE OF CONTENTS


REGULATORY AND SAFETY	III
FCC Certification and More:.....	iii
ESD Handling Instructions.....	iii
Safety Notice	iii
Hygiene, Health, and Safety	iii
Battery Disposal	iii
Disclaimer	iii
WHAT'S IN THE BOX	1
TOOLS/EQUIPMENT/MATERIAL REQUIRED.....	2
INSTALLATION OVERVIEW	3
Wiring connections (Not all connections are required)	4
INSTALLATION	6
Before you begin	6
The Base Station and Connections	6
Installing the System	6
Examples of RT7000 Mounting Locations.....	9
Wiring Diagram when connecting with the IB7000, SS7000 (or SP10) & DM5.....	10
Wiring Diagram when connecting with the SP7000 & DM5	11
INSTALLATION WIZARD OVERVIEW	12
Stage 1: Welcome	12
Stage 2: Connect.....	12
Stage 3: Configure.....	14
COMPONENT NOTES	15
Cable Pulling	15
Remote Transceiver (RT7000).....	15
The Smart Battery Charger (AC70)	17
Headset (HS7100 & HS7000)	19
Voice Commands	20
Setup and Operation	20
Crew Profiles and Positions.....	21
SPEAKER POSTS AND ENCLOSURES	23
Dedicated PVC Conduit Requirements	23
Speaker Post/Menu Board Size Requirements	23
INSTALLING THE IB7000	24
Installing the weather cover	25
INSTALLING THE MICROPHONE AND SPEAKER	26
The DM5 Microphone.....	26
The SS7000 Speaker (Standard, if not using the SP10).....	27
The SP10 Speaker (Optional, if not using the SS7000)	28
The SP7000 Speaker (Combines the SPEAKER and IB into one unit)	29
INSTALLING THE TI7000 TELEPHONE INTERFACE (OPTIONAL).....	32
VAIO (VOICE AI ORDERING)	34
Telemetry	35
ZOOM NITRO FEATURES	37
Nitro Alerts	37
Nitro Vision AI.....	38
HELP	39
Troubleshooting	39
VAIO Troubleshooting	40
Troubleshooting Screens	42
Additional Troubleshooting	48
Firmware Updates.....	49

Glossary of terms	50
VAIO Glossary of terms	52
SPECIFICATIONS.....	53

WHAT'S IN THE BOX

1. Base Station (BS7000) with power adapter
2. Headset (HS7000/HS7100) and battery (BAT70)
3. Radio Transceiver (RT7000)
4. Battery Charger (AC70) with power adapter
5. Post Components such as SP7000 speaker & DM5 microphone (the IB7000 and SS7000 or SP10 speaker are components also supported but are not shown here)
6. Quick Start User's Guide
7. Hardware and cables (not shown)
8. Acoustic Foam (not shown)

The system contents in the box will vary depending on the customer's order. Quantities of certain components, such as headsets and batteries, will also vary. However, the components listed here are the basic components generally included with a complete NEXEO® system.



TOOLS, EQUIPMENT, AND MATERIALS REQUIRED

General Tools/Equipment

- General hand tools, screwdrivers, cutters, pliers, and wrenches
- Standard Drill (for wall-mounted installations)
- Drill bit set (sizes 1/16 in. - 1/2 in.)
- Wire strippers
- Soldering Iron and solder
- Tape measure
- Pencil/marker
- Crimp caps or shrink tubing with heat gun
- Serrated knife
- Cable-pulling equipment: fish stick/tape, pull strings, etc.
- Ladder

Specialty Tools/Equipment

- N/A

Materials

- Cable ties (for bundling any cable slack, available at most hardware/home improvement stores).
- Mounting hardware (while general hardware is provided for mounting system components, specialty hardware may be required, such as masonry screws for brick or concrete walls).
- Electrical tape and twist-on wire connectors
- Audio cable
- Acoustic Foam
- Specialty hardware (if required beyond what is included)

Safety Equipment

- Safety Glasses
- ESD grounding strap (recommended when connecting to the PCBA in the Base Station)

INSTALLATION OVERVIEW




Fig. 1.1

WIRING CONNECTIONS (NOT ALL CONNECTIONS ARE REQUIRED)

J600 (Ceiling Speakers)		
Pin #	Label	Descrptn/wire color
1	Ceiling Spkr1 +	Speaker 1 positive
2	Ceiling Spkr1 -	Speaker 1 negative
3	GND	Ground
4	Ceiling Spkr2 +	Speaker 2 positive
5	Ceiling Spkr2 -	Speaker 2 negative
6	GND	Ground




Fig. 1.2


J201 (Telephone Interface)		
Pin #	Label	Description/wire color
1	Tel Audio In	
2	Tel Power +12V	
3	Tel Off Hook	
4	Tel PTT	
5	Tel Ring	
6	Tel Active	
7	Tel Ground	
8	Tel Audio Out	

J800 and J801 (Lane 1 & 2 Timer)		
Pin #	Label	Description/wire color
1	Greet Out (Analog)	Greet Out 1 for J800 Greet Out 2 for J801
2	GND	Ground for J800 and J801
3	N/C	Not connected
4	Alt Grt Out (Digital)	Alt Greet Out 1 for J800 Alt Greet Out 2 for J801
5	GND	Ground for J800 and J801
6	Veh Det Out Com	Veh Det Out Com1 for J800 Veh Det Out Com2 for J801
7	Veh Det Out N.O.	Veh Det Out N.O.1 for J800 Veh Det Out N.O.2 for J801
8	Veh Det Out N.C.	Veh Det Out N.C.1 for J800 Veh Det Out N.C.2 for J801

J802 (Vehicle Detect Inputs)		
Pin #	Label	Description/wire color
1	+12 V	Power
2	N/C	Not connected
3	Veh Det In 1	Vehicle Detect In 1
4	GND	Ground
5	Veh Det In 2	Vehicle Detect In 2
6	GND	Ground

J803 (Early Warning Inputs)		
Pin #	Label	Description/wire color
1	Erly Wrn In 1	Early Warn In 1
2	GND	Ground
3	N/C	Not connected
4	Erly Wrn In 2	Early Warn In 2
5	GND	Ground

J804 (Remote Switch Inputs)		
Pin #	Label	Description/wire color
1	GND	Ground
2	OO in 1	Outside Order in 1
3	Ded in	Dedicated In
4	OO in 2	Outside Order in 2
5	GND	Ground



Base Station Power Supply:

1. Terminate the positive wire of the power supply to J1 DC + terminal (pin 1).
2. Terminate the negative wire of the power supply to J1 DC - terminal (pin 2).
3. Terminate the shield to J1 GND terminal (pin 3).

Note: Only use the HME power supply provided with your system.

INSTALLATION

BEFORE YOU BEGIN

Survey the premises with store manager to determine the optimal mounting locations for each component. Take into consideration:

- The system requires a region code to operate, so an Internet connection and an HME CLOUD account are necessary. Connect to HME CLOUD and verify connectivity before installing the RT7000.
- Cable lengths for hardwired components, such as the remote transceiver and network connections, may limit the available locations.
- Proximity to power outlet and network router.
- If mounting the Base Station in an area with high foot traffic, consider carts and mobile shelving units, as they can damage the Base Station if they come into contact with it.
- Selecting an appropriate location for the remote transceiver is critical (see Fig. 2.10 and 2.11). Also read about the “Remote Transceiver (RT7000)” on page 14 under Component Notes and review the Critical Steps in the following instructions.

THE BASE STATION AND CONNECTIONS

The Base Station is the control center and focal point of the NEXEO | HDX™ system. System features and all connections are configured and terminated here. This is also where store personnel interact with the system when setting up profiles and pairing headsets. If you are replacing an existing HME product, such as an EOS|HD® system, you may be tempted to reuse the existing wires/cables without rerouting new ones. However, the customer has purchased a new system that requires routing new cables. **Please discard the old cables and route new cables.**



CAUTION: Wear appropriate eye, ear, and body protection when drilling, grinding, or performing other installation tasks. Follow the manufacturer’s safety instructions and operating procedures for all tools and materials. Remain aware of your surroundings at all times. Failure to follow these precautions may result in personal injury, equipment damage, or property damage. Before drilling, verify that the area behind the mounting surface is free of electrical wiring, plumbing, and other hazards.

INSTALLING THE SYSTEM

1. The Base Station should be mounted in a location that is easily accessible to all crew members and available at all times (for example, not in a locked office with limited access).
2. Mount the Base Station at a height that allows the touchscreen to remain visible and within comfortable reach for normal operation. The recommended mounting height is 5 ft. (1.52 m) from the floor (see Fig. 2.1).

Note: Determining mounting height should also account for personnel with disabilities, such as wheelchair users.

3. There are two latches along the top side of the Base Station (see Fig. 2.2). Unlatch these to open the Base Station cover (the cover does not completely detach as it is hinged on the bottom side). Four mounting keyholes are visible, one at each corner through




Fig. 2.1

the legs (see Fig. 2.3). Use a pencil to mark the wall through these holes (avoid touching the exposed PCBA unless you are wearing a ground strap). Drill four pilot holes (3/16 in. drill bit). Push the four plastic anchors into the holes until flush, then insert the four screws provided, but do not tighten. Leave enough space to mount the Base Station over the head of the screws, then slide it down. Tighten screws to secure the Base Station.

4. Mount the power supply. Mark the mounting location on the wall through the mounting holes on each side. Mount the power supply using the hardware provided. Terminate the power supply to the Base Station (see "Wiring connections (Not all connections are required)" on pages 4 and 5).
5. **Critical Step:** Loosely mount and connect the RT7000 (Fig. 2.4 & 2.5) in a central location for optimal coverage (until range tested in steps 9 & 10 with the Installation Wizard). For example, notice Fig. 2.10 and 2.11. They show two different store layouts with specific targeted areas where the headsets are primarily used. In these examples, the location selected for the RT7000 (represented by the small blue rectangle) provides the best coverage, as indicated by the blue-circled areas. Each store required the RT7000 to be mounted in a different, yet central, location to provide the best all-around coverage tailored to the store's needs. Store layout and obstructions also affected placement and range. (see "Component Notes" on page 15 for more details on the RT7000 placement).



CAUTION: If the RT7000 needs to be relocated, wait at least 5 seconds after unplugging it before re-connecting the cable to the same base station port. This allows time for the system to turn off power to the port; connecting to a live port can damage the circuitry. Or, reconnect it to a different port.

6. Install the other components. The DM5 microphone and SS7000 speaker, or SP10 speaker, must be installed using the IB7000 interface box. Use Fig. 2.12 as a wiring reference and see "Component Notes." for more installation details.
7. Route and terminate all component cables to the Base Station using the wiring references in this guide. Consult the store's IT personnel when connecting to the network router.
8. Terminate the Base Station power supply and connect to outlet. The Base Station turns on automatically and performs a self-check to confirm that everything is operating correctly.
9. On the Base Station UI, follow the Installation Wizard to




Fig. 2.2




Fig. 2.3

RT7000 TRANSCEIVER
Rear View




Fig. 2.4




Fig. 2.5

connect and configure the system (see Fig. 2.6).
Note: If you accidentally exit the Installation Wizard, log in to the Base Station, select **SYSTEM > TROUBLESHOOTING**, choose Installation Wizard from the drop-down menu, and tap Start Installation Wizard.

10. **Critical Step:** During the **Configure** stage of the Installation Wizard, **Transceiver Installation Step 2** prompts you to use a paired headset in **Reception Location Mode** (Fig. 2.7). After pairing a headset, the Reception Location Mode indicator changes from **OFF** to **ON** (Fig. 2.8). Tap **Continue** to proceed to **Transceiver Installation Step 3**. Walk through all areas where the headset will be used to verify signal coverage. The Boom LED flashes different colors to indicate signal strength. The NEXEO screen displays the same color-coded information (see Fig. 2.9). Reposition the Remote Transceiver as needed to achieve optimal coverage.

Note: Depending on the store layout and coverage requirements, additional Remote Transceivers may be required. Also see the **CAUTION** in Step 5.

11. After verifying the Remote Transceiver location, secure all loosely mounted components.
12. Test audio levels between the headsets and drive-thru order points. Adjust as needed using the volume controls on the Base Station UI.
13. Use cable ties to bundle and provide strain relief for cables exiting the Base Station. Secure the cable bundle to one of the rear housing cross-bars.
14. Close the Base Station. The system is now ready for use.

Note: See **Component Notes** (page 15) for additional component information and **Setup and Operation** (page 20) for system operation details. If a fault or failure occurs, verify system configuration using the Installation Wizard under **SYSTEM > TROUBLESHOOTING**. Also, reference “Help” on page 37 of this guide.




Fig. 2.6




Fig. 2.7




Fig. 2.8




Fig. 2.9

EXAMPLES OF RT7000 MOUNTING LOCATIONS




Fig. 2.10





Fig. 2.11


WIRING DIAGRAM WHEN CONNECTING WITH THE IB7000, SS7000 (OR SP10) & DM5

NOTE: See Installing the System and individual component sections in guide for detailed instructions



WIRING DIAGRAM WHEN CONNECTING WITH THE SP7000 & DM5

NOTE: See Installing the System and individual component sections in guide for detailed instructions



INSTALLATION WIZARD OVERVIEW

Once the system is installed and connected, the Base Station turns on automatically when plugged into an electrical outlet. The Installation Wizard is the first screen you'll encounter if the Base Station is new and not yet configured. You will need your installer's password to access the Installation Wizard. The following information provides an overview of the Installation Wizard, but does not include every screenshot or step involved in completing the installation. The Installation Wizard will guide you through this process.

There are three main setup stages: Welcome, Connect, and Configure. Each stage has several associated steps (screens) that are completed in sequence to advance to the next step unless you have the option to "Skip." Completed stages are indicated by a checkmark (e.g.,  Welcome in Fig. 3.2). The current stage you are in is indicated in blue (e.g.,  Welcome in Fig. 3.1), while stages yet to be completed are in gray.

STAGE 1: WELCOME

After initiating the Installation Wizard, this screen prompts you as to what is needed before continuing.





Fig. 3.1

Click the  button to proceed. The next screen provides an overview of the stages involved. You have a choice of Manual Setup or Use Wizard. We recommend you use the Wizard.

STAGE 2: CONNECT

This stage connects the system. First, add Store Details, then continue to next page. Connect To Network and HME CLOUD. DHCP allows a network administrator to supervise and distribute IP addresses from a central point. When the DHCP is enabled, the system automatically populates the required fields. Consult the Glossary definitions.




Fig. 3.2

This part of the Installation Wizard also asks you to enter a “Registration Key.” The registration key can be found on the Sales Order and allows the customer to link their NEXEO System to the Store. The registration key is then used to register the device. This can be done here through the Installation Wizard or on the HME CLOUD screen after the Installation Wizard is complete (Fig. 3.4). Verify that the registration key matches the store info (Fig. 3.5).




Fig. 3.3




Fig. 3.4




Fig. 3.5

STAGE 3: CONFIGURE

This stage configures the system. Options such as Lane Setup, Remote Transceiver positioning, Update Options, and Headset Registration are configured here.




Fig. 3.6

Note: If you accidentally exit the Installation Wizard and need to return to it. Log in to the system, go to the SYSTEM page, and under the TROUBLESHOOTING tab, select "Installation Wizard" from the drop-down list. Tap the "Start Installation Wizard" button to begin (see Fig. 3.7).




Fig. 3.7

COMPONENT NOTES

CABLE PULLING

All NEXEO orders include a new cable pull installation. While it is possible to use the existing cables from an HME system you are replacing, it is recommended that all NEXEO installations use new cables to ensure optimal performance. The customer is paying for a new system, and this includes new cables!



CAUTION: *Never run high-voltage cables in the same conduit with audio or loop cables.*

1. Run fish tape from inside the building, through the conduit to the speaker post or menu board.
2. Go outside for the cable going to the speaker post. If you are pulling more than one identical cable, mark the cables and spools for identification. Fasten each cable to the fish tape where it comes out of the conduit.
3. Pull the fish tape and cable through the conduit into the building. Disconnect the cable from the fish tape and pull enough of it in to reach the base station.
4. Go back outside and run the cable from the outside conduit to the speaker post or menu board.
5. Cut the cable, leaving about 3 feet (91 cm) of slack (or enough length to easily route the cable through the speaker post and terminate it). If more than one cable has been pulled, mark the ends of the cables again for identification.
6. Remove about 2 inches (5 cm) of the outer insulation from the end of each cable. Strip about $\frac{1}{2}$ inch (12 mm) of insulation from each of the wires in the cable.
7. Route all the cables together to the base station, through walls, and over ceiling panels if possible. Make sure that any cable slack is bundled, secured, and out of the way if left in the ceiling or elsewhere.

REMOTE TRANSCEIVER (RT7000)

The RT7000 Remote Transceiver (Fig. 4.3) is a required component that enables Base Station-to-Headset communication. It uses a wired connection to the Base Station but communicates wirelessly with Headsets. Up to four RT7000s can be connected to the Base Station to provide greater coverage for larger/multi-level premises.

Installing the Remote Transceiver (RT7000):

- The RT7000 is omnidirectional, so mount it high in a central location where the headsets are typically used (see Fig. 4.1).
- Maximize line of sight between the transceiver and headsets in an area free from obstructions and equipment/materials that can interfere with signal propagation. These include walls, large metal appliances, hoods, and backsplashes, etc.
- Mount the transceiver vertically on a wall in the upright position (see Fig. 4.4 and orientation arrow on the RT7000 rear). Do **NOT** mount horizontally, such as on a ceiling; this will severely reduce the transceiver's range.
- The RT7000 uses an Ethernet cable (Cat5 or Cat6). Do not exceed 500' (152 m).
- Large premises may require more than one transceiver. Up to four transceivers are supported by the




Fig. 4.1

Base Station (PCBA ports: J3200, J3400, J3600, and J3800).

- Once connected to the base station, the LED in the middle of the circle on the transceiver front illuminates to indicate it is turned on. One of the outer LEDs (numbered 1 to 4) around the circle also turns on (depending on which port the transceiver is connected to on the base station, Fig. 4.2 shows the RT7000 connected to the first port (J3200), also see Table 1). This outer LED will initially flash in Magenta, blue, or yellow (see Table 2) as the transceiver scans for available channels, then turn solid green once a channel is found. (On the base station HOME screen, the transceivers' indicator is yellow while scanning before turning green.)




Fig. 4.2




Fig. 4.3

Remote Transceiver ports on Base Station PCBA			
Connector Label	Status/Description	To	LED #
J3200	Remote XCVR Module 1	First RT7000	1
J3400	Remote XCVR Module 2	Second RT7000	2
J3600	Remote XCVR Module 3	Third RT7000	3
J3800	Remote XCVR Module 4	Fourth RT7000	4

Table 1

* RT7000s can be connected to any port in any order and do not have to follow this table.

RT7000 LED Colors with Functional Description	
Color (LEDs 1-4)	Functional Description
Green (Solid)	Ready for use. RT7000 is broadcasting, and headsets can connect.
Magenta (Blinking)	WiFi Scan.
Yellow (Blinking)	Radar Scan.
Yellow (Solid)	RT7000 is in Test Mode.
Blue (Blinking)	Main radio or Radar1 radio is updating.
Cyan (Blinking)	Radar2 radio is updating.
Red (Solid)	RT7000 has reset and is starting initialization.

Table 2




Fig. 4.4

- A surge protector/lightning arrestor is recommended if the RT7000 is mounted outside on an exterior wall. See Fig. 4.5. The ground lug supports up to 12 AWG wire, but check with your municipality for local codes on appropriate grounding. With bidirectional protection, either RJ45 jack can be used. Contact HME if one or more are required.




Fig. 4.5

THE SMART BATTERY CHARGER (AC70)

The AC70 Battery Charger can charge up to four BAT70 lithium-ion batteries simultaneously. LEDs at the charging ports indicate battery status. Charge time is two hours. The AC70 can be used on a desktop or mounted on a wall.


INSTALLATION/SETUP AND OPERATION

Desktop instructions:

1. Place the AC70 on a level desktop or shelf.
2. Connect the power adapter to a wall outlet, and the other end to the power connector on the AC70 (Fig. 5.1 & 5.2).
3. Position the BAT70 battery correctly for insertion into the AC70 (it is keyed and can only be inserted one way).
4. Insert the BAT70 battery into a vacant port to begin charging. LED activity indicates the battery's status (see table below).

Battery Charger LED Reference Table		
LED	Color	Status/Description
	Green	Flashing Green = Charging Solid Green = Fully charged
	Red	Flashing Red = Incompatible battery
	Red/Yellow	Flashing Red & Yellow (alternating) = Fault condition
	Blue	Firmware upgrade in progress

Base Station HOME screen Status Indicators



Note: The AC70 requires close physical proximity (<10 ft (3 m)) to the base station to monitor battery status on the base station HOME screen. When within range, the Chargers indicator on the HOME screen changes from  (gray) to  (green). Then, tap **Chargers** to view battery status, tap a port # tile for details (see Fig. 5.3).






Fig. 5.3



Note: Only use the HME approved Power Adapter provided.

Fig. 5.1



Note: Storage Ports do not charge batteries

Fig. 5.2

CHANGING POWER SUPPLY ADAPTER

1. Replace power adapter (P/N: CON-00004) to match your country's outlet by using your thumb and forefinger to squeeze in on both sides of the latch (see Fig. 5.4).
2. Continue squeezing latch and slide the adapter out, away from the power supply to remove.
3. Release the latch and slide another adapter on until it bottoms out and the latch clicks to secure it in place.




Fig. 5.4

WALL MOUNTING TEMPLATE FOR AC70

1. Hold template (Fig. 5.5) against wall.
2. Use a marker to punch through the paper template at the two crosshairs to mark the wall.
3. Drill two holes at the marks on the wall (avoid electrical or plumbing obstructions).
4. Install the provided hardware, but do not tighten; leave a gap ($\sim 1/8^{\text{th}}$ inch (3.2 mm)) between the screw heads and wall.
5. Align the AC70 mounting keyholes with the two screws.
6. Mount the AC70 over the screw heads until flush against the wall, then slide it down onto the screw shanks to secure it in place.




Fig. 5.5

HEADSET (HS7100 & HS7000)

The HS7100 & HS7000 are headsets (Fig. 6.1) used to communicate with crew and customers in a store or drive-thru lane environment. They use a BAT70 lithium-ion battery. Under normal use, the headset will operate for approximately eight hours on a single battery charge (new battery) and will alert you when the battery charge is low. During periods of inactivity, the HS7100 headset will enter sleep mode to conserve power. Move the headset to wake it up from sleep mode.




Fig. 6.1

Keypad Reference Table				
Icon	Label	Status LED	Boom LED	Status/Description
1	Lane 1	Green	Green	Tap to talk to lane 1. The Status LED flashes green while the Boom LED turns on solid green (with an audible single-tone confirmation). Tap again to stop (with two-tone confirmation).
2	Lane 2	Red	Red	Tap to talk to lane 2. The Status LED flashes red while the Boom LED turns on solid red (with an audible single-tone confirmation). Tap again to stop (with two-tone confirmation).
	Volume Up			Tap to increase volume (the headset beeps become louder as confirmation). Press and hold to maximize volume to loudest level.
	Volume Down			Tap to decrease volume (the headset beeps become quieter as confirmation). Press and hold to minimize volume to quietest level.
	Group/Crew			Tap for group/crew chat. Both Status and Boom LEDs flash quickly, alternating red & green (with an audible single-tone confirmation). Tap again to stop (audible two-tone confirmation). The Status LED changes to a solid yellow in listening-only mode.
	Action			If the headset is set to answer phone calls. Tap once to answer, tap again to end call. Press the 1 or 2 key twice to put the phone call on hold and talk to a respective lane. Press 1 or 2 once respectively, followed by the Action key to return to call. Press again to end call.

Notes: Both the Status and Boom LEDs flash slowly alternating colors when the headset needs to be paired. A yellow Status LED indicates a low battery. The low battery Status LED is also accompanied by audio prompts.

Voice commands: See Voice Commands on page 18.

Push-to-Talk mode: Press and hold (continuously) any audio key (L1, L2, or Group) to use in this mode (there is an audible single-tone confirmation). Release to cease communication and exit this mode (there is an audible two-tone confirmation).

VOICE COMMANDS

This option allows headset users to operate their headset with audible commands instead of using the headset keypad. Voice commands are not available with NEXEO | Core and must first be enabled on the base station (SYS-TEM>SETTINGS>Voice Commands). The following table lists available voice commands. All voice commands must be initiated by the command “OK NEXEO” followed (within ten seconds) by the specific command prompt listed in the table below.

Voice Command Table			
How to:	Say:	Status LED	Boom LED
Begin conversation with Lane 1 customer	OK NEXEO, talk to Lane 1	Flashes Green 	Flashes Green 
Begin conversation with Lane 2 customer	OK NEXEO, talk to Lane 2	Flashes Red 	Flashes Red 
Change to listen only to Lane 1 group	OK NEXEO, Lane 1	Solid Green 	Solid Green 
Change to listen only to Lane 2 group	OK NEXEO, Lane 2	Solid Red 	Solid Red 
Set volume level	OK NEXEO, volume # (1-15, 0 is mute)	No effect	No effect
Increase volume or Decrease volume	OK NEXEO, volume up, or volume down	No effect	No effect
Change to the opposite lane's group	OK NEXEO, change lane	To L2 Solid Red, L1 Solid Green	To L2 Solid Red, L1 Solid Green
Person-to-person*	OK NEXEO, call [name of person]		
Call a group/position**	OK NEXEO, call [name of group/position]		

* The person must exist in the Crew Profile directory. First, last, and full names can be used. Tap  on the headset to exit and return to the previous state.

** This needs to be a designated position. Tap  on the headset to exit and return to the previous position.

SETUP AND OPERATION

Note: The HS7100 and HS7000 are wireless and have an optimal range in which signal strength is best. This depends on the location of the Remote Transceiver RT7000 and the line of sight between it the headset.

1. With a fully charged BAT70 battery installed, move the headset to power on (if using the HS7100 headset and it is in sleep mode) or press the blue power button to turn it on (if using an HS7000 headset). The status LED turns on green and blinks, alternating between green and red, indicating you now need to pair the headset.
2. Hold the keypad side of the headset against the Headset Pairing Ring (solid blue circle) on the Base Station to pair (Fig. 6.2). Pairing begins automatically as soon as the headset is sensed.
3. When the Headset LEDs stop alternating green and red and the status LED turns solid green, pairing is successful. If pairing fails, see note.
4. Select your position (see following section: Crew Profiles and Positions) and begin using the headset.




Fig. 6.2

Notes: If pairing is unsuccessful, try again by first verifying that the headset is on and the battery is fully charged. Hold the headset steadily centered and flush against the Headset Pairing Ring (headset movement or distance from the Pairing Ring can cause pairing errors). A weak battery might also result in pairing issues, replace with a fully charged battery as necessary. Registration automatically happens with the initial pairing.

CREW PROFILES AND POSITIONS

Once your headset is successfully paired, one of two dialog boxes appears. If no crew profiles are set up in the system, Fig. 6.3 will appear. Tap the **No, Skip** button to continue as a guest (this opens the **Select Your Position** dialog, see Fig. 6.5). Or, tap the **Yes, Add New Crew Profile** button




Fig. 6.3

If an existing Crew Profile exists, the **Select Your Name To Pair** dialog opens (see Fig. 6.4). Tap on your name if it already exists (names are listed in alphabetical order, so you may have to scroll down the list to find it), or tap on the **Continue as guest** option in the upper left if you don't have a profile.




Fig. 6.4

NOTE: Crew Profile is only available for NEXEO and NEXEO Pro tiers. If this option is grayed out, it is because you are using NEXEO Core, or because your brand administrator has disabled it.

When the **Select Your Position** dialog appears (Fig. 6.5), you are prompted to select a position. Tap on one of the available tiles to select it (DRIVE-THRU 1 is selected in Fig. 6.5).




Fig. 6.5

The **Customize Positions** button at the bottom of the dialog box lets you select from a range of positions that best reflect your store. Additional Positions (located in the drop-down list under System>Settings) lets you choose up to five additional positions. Just tap or click on a position tile to select it. When finished, save your selection (the Save button only becomes active after selecting at least one position, see Fig. 6.6). This selection will then appear in the Select your Positions dialog box (Fig. 6.5).




Fig. 6.6

Group/Crew Chat: By default, group/crew chat is separated by position, allowing communication only among users assigned to the same position. This is the standard operating mode. For example, Drive-Thru 1 users hear only Drive-Thru 1 users, Front Counter users hear only Front Counter users, and Manager users hear only Manager users.

If a brand administrator has requested Unified Crew Chat, it overrides the standard operating mode so that all active positions are combined into a single group. This allows everyone to communicate regardless of their position.

SPEAKER POSTS AND ENCLOSURES

Before installing the Speaker, Microphone, and IB7000, you must determine where these components will fit.

DEDICATED PVC CONDUIT REQUIREMENTS

The NEXEO cables running from the Speaker Post to the inside of the store must use a dedicated PVC conduit that is at least one inch (25.4 mm) in diameter. One conduit is needed for each lane. Straight runs are recommended. No other wiring or cable may share the HME conduit.


SPEAKER POST/MENU BOARD SIZE REQUIREMENTS

The inner space dimensions of speaker posts/menu boards must be large enough to accommodate three components: a speaker, a microphone, and an interface box (not necessary if using the SP7000 speaker). The maximum component **Height = 5.9"**, **Width = 5.9"**, and **Depth = 4.6"**, so you will need a post space with at least that much three-dimensional space to fit any given component (this does not account for the acoustic foam also used to secure the components). Component dimensions are listed under "Specifications" on page 53.

- **Microphone:** The microphone should be installed 42 inches from the ground (the average car/truck height at which the mic element would meet the middle of the face), and two inches of foam should be packed around the microphone to prevent vibrations from disturbing it.
- **Speaker:** Once the microphone is in place, the speaker should be at least two feet away from the microphone (below or vertically).
- **IB7000:** The IB7000 is mounted vertically in the post using the adhesive strips (but with no foam).
- **SP7000:** This combines both the IB and Speaker into one device and is mounted like the speaker.

NOTE: If all the components cannot fit comfortably in the post, extra space can be created by installing the components externally using the SPE1 enclosure, which can be attached to a menu board. Only one SPE1 may be required for the speaker, but up to three can be used if the microphone and IB7000 must be installed externally (possible mounting locations are shown below).

DO NOT install the IB7000 in an SPE1 enclosure shared with another component, because it should not be packed with foam. In the event it needs an enclosure, a separate SPE1 should be used. The SPE1 enclosure has its own installation guide and can be found on our website.



INSTALLING THE IB7000

The **IB7000** interface box is required when connecting the **DM5** microphone and **SS7000** speaker or **SP10** speaker to **NEXEO**. Adhesive strips allow the **IB7000** to be affixed to a clean, dry surface inside the speaker post. The max **IB7000** cable length to guarantee operation at max volume should not exceed 500 ft (152 m). Fig. 7.2 and Fig. 2.12 (on page 10) show how the **IB7000** is typically connected.

Note: The **IB7000** must be mounted vertically, inside the speaker post, close to the speaker/microphone. This will help minimize audio hum and noise (do not mount the **IB7000** too far away). If more than one **IB7000** is being installed, note the serial numbers, so you know where each is assigned during configuration on the base station. The power LED illuminates green when the **IB7000** is connected to a powered-on base station.




Fig. 7.1

- The two-pin Loop connector connects to the ground loop.
- The three-pin PLC/BASE connector connects to J4500 on the base station. This connection requires the shield/drain to be grounded; see Table 1.
- The seven-pin DM5 MIC | SPKR connector connects to the Microphone and Speaker; see Table 2.
- The five-pin RELAY | BCKP SPKR connector (optional) connects to an intercom system such as the IC300 if a backup is needed in the event of a system failure.

IB7000 PLC connector to Base Station J4500 (Spkr/Mic Intrfc)			
Pin #	IB7000 PLC Label	Pin #	Base Station J4500 Label
1	IN1/PL+ (Red wire)	1	Spkr/Mic PL + (Lane 1)
2	IN2/PC- (Black wire)	2	Spkr/Mic PL - (Lane 1)
3*	GND - (Shield/drain)	3	Shield (Lane 1)
1	IN1/PL+ (Red wire)	4	Spkr/Mic PL + (Lane 2 of Y-Lane or Dual-Lane)
2	IN2/PC- (Black wire)	5	Spkr/Mic PL - (Lane 2 of Y-Lane or Dual-Lane)
3*	GND - (Shield/drain)	6	Shield (Lane 2 of Y-Lane or Dual-Lane)

Table 1

IB7000 DM5 MIC SPKR connector to Speaker and Mic			
Pin #	IB7000 Label	Description/wire color	Speaker/Mic labels
1	Mic +	Ext. Microphone positive	DM5 +ve (red)
2	Mic -	Ext. Microphone negative	DM5 -ve (black)
3*	GND	Mic Shield (must be terminated)	DM5 Drain/Shield
4**	I.D.	1-WIRE I/F (Red)	Only for SS7000
5**	GND	Ground (Black)	Only for SS7000
6	Spkr -	Speaker negative (White)	SS7000 or SP10 -ve
7	Spkr +	Speaker positive (Green)	SS7000 or SP10 +ve

Table 2

- * The Shield/Drain on the DM5 and audio cable from the **IB7000** PLC must be grounded.
- ** Pins 4 and 5 are only used if connecting an **SS7000** speaker (not used with **SP10**).

INSTALLING THE WEATHER COVER

The IB7000 Weather Cover **must** be installed on the IB7000 to protect the electrical connections from corrosion due to water/moisture ingress. (Even when installed in a speaker post or menu board, these locations do not guarantee a sheltered environment for the IB7000.)

When installed, the weather cover completely seals the IB7000, preventing water or moisture from entering. The bottom has an opening to allow all the IB7000 cables to exit beneath the IB7000 once the cover is in place.




Fig. 7.2

Note: The cover must be oriented and installed correctly to be effective (see Fig. 7.2).

1. Orient the weather cover correctly before installing (see the up arrow on the cover rear, Fig. 7.2 & 3).
2. Attach the cover by placing the top latch over the ridge and housing seam of the IB7000 (Fig. 7.4).
3. Then, hinge the bottom part of the cover onto the bottom part of the IB7000. If there is resistance, the bottom latches are flexible and can be pried outward and onto the IB7000 (Fig. 7.4).
4. Verify that all the IB7000 cables exit through the bottom opening of the cover before pressing the cover in to close. The cover will snap securely into place (Fig. 7.5).




Fig. 7.3




Fig. 7.4




Fig. 7.5

Note: To remove the cover, do so in reverse order to the above steps. First, use your fingers to pry the flexible latches on the bottom of the cover as you detach it from the IB7000 ridge and housing seam it is gripping. Hinge outward away from the IB7000 until the top freely detaches.

INSTALLING THE MICROPHONE AND SPEAKER

THE DM5 MICROPHONE

The DM5 must be used in conjunction with the IB7000 interface box (i.e., the microphone does not connect directly to the base station).

- See Fig. 2.12 on page 10 for visual reference and IB7000 section for wiring tables.

A typical DM5 Microphone installation involves placing the microphone in a molded foam enclosure and mounting it in the upper compartment of the speaker post. You will fill the empty space behind the unit with acoustic foam. If the DM5 is mounted in a small area, its molded foam enclosure may need to be compressed to close the compartment. Follow these instructions to install the DM5 in a typical speaker post or menu board.

1. Open the speaker post and remove any existing equipment, foam, or debris. If there is an existing microphone, remove it and disconnect the microphone cable.
2. Remove the small portion of the provided foam microphone enclosure, resulting in the two pieces of foam shown in Fig. 8.2.
3. Insert the DM5 Microphone cable through the hole in the foam enclosure, and place the microphone into the hole as shown in Fig. 8.2.
4. Insert the removed piece of foam back into the hole in the foam enclosure fitting it snugly against the back of the microphone, as shown in Fig. 8.2.
5. Using a serrated knife, trim the foam enclosure so it is $\frac{1}{4}$ to $\frac{1}{2}$ inch larger than the upper speaker post compartment (vertically and horizontally) for a compressed fit. Keep the foam pieces to fill the compartment (if needed).
6. Place the foam windscreen in front of the microphone, positioning it to cover the inside of the speaker grill as shown in Fig. 8.3.
7. Place the foam-enclosed microphone into the compartment, so the front of the microphone windscreen is flush against the metal, centered on the grill, see Fig. 8.3.
8. The DM5 wires are connected to terminals 1, 2, and 3 of the seven-pin DM5 MIC | SPKR connector on the IB7000. See Fig. 2.12 and "Wiring connections (Not all connections are required)" on page 4.
9. Pack acoustic foam into the empty space behind the DM5 Microphone and its foam enclosure, filling it.



Fig. 8.1




Fig. 8.2




Fig. 8.3

THE SS7000 SPEAKER (STANDARD, IF NOT USING THE SP10)

The SS7000 must be used in conjunction with the IB7000 interface box (i.e., the speaker does not connect directly to the base station).

- See Fig. 2.12 on page 10 for visual reference and IB7000 section for wiring tables.

These instructions are for a typical installation.

1. Strip approximately 1 inch (25.4 mm) of insulation from the end of the audio cable and $\frac{1}{4}$ inch (6.35 mm) of insulation from each of the four cable wires, but do not tin the wires. Connect the audio cable wires to the connector plug (the speaker connector is labeled).
2. Insert the connector plug into the speaker connector (see Fig. 9.2).
3. Position the speaker inside the speaker post or menu board, with the gasket centered against the inside of the speaker grill, as shown in Fig. 9.3. Align the gasket opening with the grill opening.
4. Remove both inserts from the molded foam enclosure, then place the foam enclosure around the speaker. Trim foam with a serrated knife if necessary. Place foam inserts behind the speaker to apply pressure to the speaker, and ensure a good gasket seal against the speaker grill opening.
5. Connect the other end of the audio cable to the IB7000. The four wires on the SS7000 connect to terminals 4,5, 6, and 7 of the seven-pin DM5 MIC | SPKR connector on the IB7000 (this connector is labeled on the IB7000), see Fig. 2.11.
6. Connect audio cable between the three-pin PLC/BASE connector on the IB7000 and J4500 on the base station (this connector is also labeled on the IB7000). See Fig. 2.12 and "Wiring connections (Not all connections are required)" on page 4.



Fig. 9.1




Fig. 9.2




Fig. 9.3

THE SP10 SPEAKER (OPTIONAL, IF NOT USING THE SS7000)

The SP10 must be used in conjunction with the IB7000 interface box (i.e., the speaker does not connect directly to the base station).

- See Fig. 2.12 on page 10 for a visual reference and IB7000 section for wiring tables.
1. Strip approximately 1 inch (25.4 mm) of insulation from the end of the speaker cable, and ¼ inch (6.35 mm) of insulation from each of the two cable wires, but do not tin the wires. Connect the speaker cable wires to the connector plug as shown in Fig. 10.2. Insert the connector plug into the connector on the speaker as shown in Fig. 10.2.
 2. Remove the double-stick tape liner, and press the adhesive side of the gasket against the front of the speaker as shown in Fig. 10.2.
 3. Position the speaker inside the speaker post or menu board, with the gasket centered against the inside of the speaker grill as shown in Fig. 10.3. The cable connector can be routed to either side. Align the gasket opening with the grill opening.
 4. Remove both inserts from the molded foam enclosure, then place the foam enclosure around the speaker. Trim foam with serrated knife if necessary. Place the removed foam inserts behind the speaker to apply pressure to the speaker and ensure a good gasket seal against the speaker grill opening.
 5. The SP10 wires are connected to terminals 6 & 7 of the seven-pin DM5 MIC | SPKR connector on the IB7000 (this connector is labeled on the IB7000).
 6. Connect audio cable between the three-pin PLC/BASE connector on the IB7000 and J4500 on the base station (this connector is also labeled on the IB7000). See Fig. 2.12 and "Wiring connections (Not all connections are required)" on page 4.



Fig. 10.1




Fig. 10.2




Fig. 10.3

THE SP7000 SPEAKER (COMBINES THE SPEAKER AND IB INTO ONE UNIT)

The SP7000 is a speaker used to connect the loop and microphone to a NEXEO® Base Station. It is designed for use in Quick Service Restaurant (QSR) menu boards, speaker posts, and enclosures. The SP7000 combines the IB and speaker into a single unit, eliminating the need to install both the IB7000 and SS7000 (or SP10).

Tools/Equipment Required

- General hand tools: screwdrivers, cutters, pliers, etc.
- Cable/wire terminating tools and wire strippers.
- Audio Cable (not included)
- Acoustic Foam (not included) and knife to cut foam.

NOTE: The SP7000 must be mounted vertically inside the speaker post/enclosure (arrows on the rear indicate upright position; see Fig. 11.2). The power LED illuminates green when it is connected to a powered-on base station. The connect LED illuminates green when data communication is active. For optimal performance and maximum volume, the maximum cable length should not exceed 500 ft (152 m).

These instructions are for a typical installation.

NOTE: The cable shield/drain must be terminated on all connections.

1. Strip approximately 1 inch (25.4 mm) of insulation from the end of the audio cable and ¼ inch (6.35 mm) of insulation from each of the cable wires (do not tin the wires). Connect the cable wires to the connector plug.
2. Position the speaker inside the speaker post or menu board, with the gasket centered against the inside of the speaker grill. See Fig. 11.3. Align the gasket opening with the grill opening.
3. Remove both inserts from the molded foam enclosure, then place the foam enclosure around the speaker. Trim foam with a serrated knife if necessary. Place the removed foam inserts behind the speaker to apply pressure to speaker and ensure a good gasket seal against the speaker grill opening.
4. The 2-pin LOOP connector connects to the ground loop detector. See Fig. 11.4.
5. The 3-pin BASE connector connects to J4500 on the base station PCBA. See Fig. 11.4 and Table 2.
6. The 7-pin MIC connector connects to the DM5 microphone. See Fig. 11.4 and Table 1.

NOTE: MIC2 is not functional on this connector.



Fig. 11.1




Fig. 11.2




Fig. 11.3

DM5 Microphone	to	SP7000 MC1
Microphone + (red wire)		Pin 1: Mic 1+
Microphone - (black wire)		Pin 2: Mic 1-
Shield		Pin 3: GND
		Pin 4: Not Connected
		Pin 5: Not Connected
		Pin 6: Not Connected
		Pin 7: Not Connected

Table 1

NOTE: Only connect to MIC1, **MIC2 pins 4-7 are not currently used.**

SP7000 BASE	to	Base Station J4500
Pin 1: PL+ (Red wire)		Pin 1: Spkr/Mic PL +
Pin 2: PL - (Black wire)		Pin 2: Spkr/Mic PL -
Pin 3: GND (Shield)		Pin 3: GND/Shield
		Pin 4: Spkr/Mic PL +
		Pin 5: Spkr/Mic PL -
		Pin 6: GND/Shield

Table 2

NOTE: If connecting a second SP7000, the audio cable will terminate to J4500 pins 4, 5 & 6.




Fig. 11.4

ClearSoundX is a proprietary AI algorithm that processes audio signals to remove background noise from audio transmissions. It is available to customers who have an SP7000 installed and have purchased one of the top two NEXEO tiers. Under System > Settings > Lane Settings, customers on a NEXEO or NEXEO | Pro tier will have “ClearSoundX” activated by default under Inbound Noise Cancellation (see Fig. 11.5).




Fig. 11.5

Customers on the NEXEO | Core tier will have “Standard” set by default under Inbound Noise Cancellation. They can upgrade to the next tier to take advantage of ClearSoundX’s enhanced audio quality. The tooltip next to the ClearSoundX button provides the customer with information about this feature and prompts them to call if they desire to use ClearSoundX (see Fig. 11.6).




Fig. 11.6

INSTALLING THE TI7000 TELEPHONE INTERFACE (OPTIONAL)

The TI7000 links a telephone to a NEXEO|HDX™ system so that one designated headset can also be used to answer incoming phone calls.

WHAT'S INCLUDED

- One TI7000 Telephone Interface
- Two Cables (Cat5 Base Station, RJ11 Telephone)
- One Jack Splitter
- Mounting Hardware

TOOLS/EQUIPMENT REQUIRED (wall mounting only)

- Drill and drill bits (~ 3/16th inch (4.8 mm))
- Screwdrivers (Phillips #2 and small slotted)
- Wire cutter/stripper and safety glasses

INSTALLATION AND SETUP

Note: The base station interface cable is short (3ft (0.91 m)). Mount the TI7000 close to the Base Station.

Wall mount instructions:

1. Hold the TI7000 against the wall and mark the wall through the two mounting holes on each end of the unit (see Fig. 12.1).
2. Drill two holes at the marked locations (avoid electrical or plumbing obstructions).
3. Insert the included screw anchors until flush with the wall. Use a screwdriver to securely mount the TI7000 to the wall using the included hardware.

Connections:

1. Unplug the store telephone from the wall port and plug the included telephone jack splitter into the same wall port.
2. Plug the telephone into one of the ports on the telephone jack splitter. See Fig. 12.1.
3. Plug one end of the included telephone interface into the other port on the telephone jack splitter and connect the other end to the RJ11 port on the TI7000. See Fig. 12.1 and 2.
4. Plug one end of the included base station interface cable into the RJ45 port on the TI7000. Open the base station and connect the other end to J201 on the base station PCBA. See Fig. 12.3 for J201 location.)



Note: The TI7000 can only be used with a land-line, and is only for use in the US and Canada.




Fig. 12.1




Fig. 12.2

OPERATION:

To set your headset to answer phone calls:

1. Set the POWER and RINGER switches on the TI7000 to the ON position (the RINGER switch enables you to hear the telephone ring tone on the headset). The TI7000 status light turns on and remains a steady red (until an incoming call).
2. Log in to the NEXEO base station and go to **SYSTEM>SETTINGS**. Select Telephone Interface from the drop-down list. See Fig. 12.4. Toggle the OFF switch ON. The recommended default values are set to 10. If necessary, the volume levels can be adjusted using the sliders.
3. Pair your headset (select your name if prompted or continue as a guest).
4. When the **Select Your Position** dialog appears, select a position and check the box labeled **Allow this headset to receive telephone calls**. See Fig. 12.5. (Since only one headset can be designated to receive phone calls, checking the box forces any previous headset assigned out of this mode.)
5. The headset  (Action) key is used to answer phone calls. Incoming calls will ring on the headset, and the TI7000 status light will slowly alternate between red and green.
 - **To answer a call:** Tap the  key once (the TI7000 status light turns a steady green). The headset status LED turns a steady blue while the mic boom flashes blue.
 - **To end a call:** Tap the  key again (the TI7000 status light reverts to a steady red).
 - **To place call on hold and speak to a lane:** Tap the 1 or 2 key **once** to place the call on hold. This returns the headset to idle mode. Tap the 1 or 2 key again to speak to lane 1 or 2, respectively. To return to the call, tap the  key. To end call, tap again.

Note: Fig. 12.6 shows the location of two potentiometers and a DIP Switch on the TI PCBA. These potentiometers are factory-set and should not need adjustment, but if they do, unscrew the four screws on the front cover of the TI7000 with a Phillips (cross-point) screwdriver. Adjust R58 for the ring level and/or R62 for the voice level as needed. Clockwise turns increase volume, while counter-clockwise turns decrease volume. Call the store phone again to verify the ring or voice level. Replace the cover on the unit when you are satisfied with the ring/voice level.

The DIP Switch is set for NEXEO by default. Switch #2 is set to ON, Switches 1, 3, and 4 are OFF.

Partial View of PCBA




Fig. 12.3




Fig. 12.4




Fig. 12.5




Fig. 12.6

VAIO (VOICE AI ORDERING)

Voice AI Ordering (VAIO) requires a NEXEO Pro service and a connection with a service provider. It’s an AI feature that uses a bot to take customer orders in the drive-thru so that staff are available to perform other roles in the restaurant. It is disabled by default and, when enabled, is configured by the provider via the HME CLOUD (Fig. 13.1). Please contact brand administration for more information.

Provider settings

Configuration History

General

Details

PROVIDER NAME

• Puja Bhagat

TOKEN EXPIRATION

* 5 Hours

LOCATION

Cloud BasedOn Premise

INBOUND AUDIO MODE

ContinuousVehicle Present

OUTBOUND AUDIO MODE

VariableFixed

URL

https://testing.com:443/valid/path/support

HTTPS PORT

WSS PORT

RECONNECTION TIME INTERVAL

SECONDS180

VOICE AGENT AUDIO SOURCE

• Unprocessed

BOT CHANNELS

• 1

BOT NAME

• testing

Fig. 13.1

HOME

CREW

VOLUME

MESSAGE CENTER

SYSTEM

HELP

LOG OUT

System

SETTINGS

TROUBLESHOOTING

UPDATES

VAIO Settings

Download logs

VAIO

ON

BOT ORDER TAKER

ENABLED

LOCATION

CLOUD Based

BOT NAME

Eric

BOT ENABLED

NO

PROVIDER URL

www.hme.com

HTTPS PORT

5555

WEBSOCKET PORT

5555

AUDIO MODE

Continuous

RECONNECTION DELAY

180 Seconds max

OUTBOUND AUDIO MODE

Fixed

AUDIO FORMAT

Clear-Sound Disabled - Unprocessed

TELEMETRY INTERVAL

10 Seconds

Fig. 13.2

VAIO: This feature enables an AI voice that is integrated with a QSR brand-specific ordering system.

BOT ORDER TAKER: This enables an AI order taker. If the provider has an AI order taker configured for the store, the AI bot will take customer orders. Disable this to turn off the AI order taker while maintaining a connection with the provider (i.e., the VAIO toggle remains ON).

BOT NAME: The name used to activate the Employee Bot functionality on the NEXEO headsets (Note: this bot name does not apply to the BOT ORDER TAKER. The Employee Bot differs from the Bot Order Taker and is used to assist store employees).

BOT ENABLED: Enables the Employee Bot (see the BOT NAME Note above).

LOCATION: This specifies the bot source location, which determines whether the bot is accessed through the CLOUD or a physical device on-premises. Adjustments should be made only during troubleshooting the device.

PROVIDER URL: This specifies the VAIO endpoint URL or IP address that the NEXEO base station will use to establish HTTPS or WebSocket connections.

WEBSOCKET PORT: The port the VAIO Provider listens on for WebSocket connections. The default number is 443.

AUDIO MODE: This specifies if the audio streaming is continuous or paused when no vehicle is present in the Drive-Thru lanes.

RECONNECTION DELAY: Reconnection delay starts at two seconds and doubles after each failed connection attempt. Delay range: 2 to 180 seconds.

TELEMETRY INTERVAL: The interval in seconds, used to send Telemetry messages to the MQTT Broker. A value of 0 disables the Telemetry messages. Values between 0 and 120 are accepted. The default value is 60.

TELEMETRY

This feature allows brands to retrieve settings information using an alternative method. NEXEO now sends a complete set of status messages for all devices upon each connection to the MQTT broker, ensuring that downstream systems always have an up-to-date view. Headset, speaker/microphone status, VAIO data, loop health, and overall system status are all reported. These messages are sent at a minimum interval of 10 seconds to prevent overload caused by repeated connections.




Fig. 13.3




Fig. 13.4

When telemetry is ON, these parameters are updated remotely via the Settings Management API through HME Cloud.

MQTT Host: The IP address of the MQTT broker. The default is 0.0.0.0.

MQTT Port: Specifies the assigned port for MQTT (Message Queuing Telemetry Transport). The default is 8883.

Keep-Alive Interval: The interval, in seconds, used to send keep-alive messages that maintain the connection with the MQTT broker. A value of 0 deactivates this mechanism. Accepted values range from 0 to 120. The default value is 10.

Username and Password: For security, NEXO can use a configured username and password to allow the MQTT broker to authenticate connections, but it can also connect anonymously if authentication is not configured.

NITRO ALERTS




Fig. 14.1

The customer must have an HME ZOOM Nitro® timer installed to use this setting. NEXEO | HDX AUDIO ALERTS must also be enabled on the HME ZOOM Nitro timer. Please consult the how-to instructional guide: **Configuring ZOOM Nitro to NEXEO | HDX Alerts** online in the Supporting Documents Library of HME’s Training Portal, or please contact HME Support at 1 800 848 4468 for more details. Visit the library using this link: <https://www.hme.com/training/supportingdocuments/?lng=1>




Fig. 14.2

This is turned off by default. Toggle the switch to ON to enable (Fig. 14.2). The HME ZOOM Nitro timer can be configured to play messages/notifications on NEXEO headsets. When ZOOM Nitro® alerts have been configured on the timer system, they show up in the TYPE column on the MESSAGE CENTER>MESSAGES page as “Nitro Alert.” Just like all other alerts and reminders, the schedule and destinations that will hear these alerts must be configured on the base station.




Fig. 15.1

This is also an HME ZOOM Nitro feature. If your drive-thru lane uses a camera instead of a loop detector, it can be configured on this page.

The VPU IP Address and Port fields are populated automatically. These fields display the same values found under Network in the ZOOM Nitro dashboard.

From the Detector fields, select the appropriate menu for each lane. In the example shown below, Menu1 is selected for Lane 1 and Menu2 is selected for Lane 2.

The Detectors page appears differently depending on whether Vision AI is turned ON or OFF.




Fig. 15.2

HME Technical Support: If the help provided in this section is not sufficient, please contact our Technical Support team at support@hme.com or call us at 1-800-848-4468. As a valued customer, we are here to help you have the best experience with your product; your success is our success!

TROUBLESHOOTING

Problem	Solution
The Base Station is off (blank screen)	The Base Station does not have a power on/off button, it turns on automatically once it is plugged into a live outlet. Verify the power adapter is plugged into a live wall outlet. Verify the power cable is properly terminated to J1 on the Base Station PCBA and that there is power from the power adapter to this end of the cable (illuminated LEDs on the PCBA indicate there is power to the base station).
The Base Station is on but not responsive to certain actions	Log in to the base station, go to SYSTEM, click on the troubleshooting tab, select from the menu and try restarting the component that is not responsive. Restarts can take several minutes to complete.
The entire HOME screen is not responsive to touch	Try a hard reset by unplugging the power cord from the wall outlet. Wait a few seconds and then reconnect power. Reboots can take several minutes to complete.
The headset does not power on	Verify the BAT70 battery is fully charged and not dead (verify charge in AC70). Verify the BAT70 battery is inserted correctly and properly docked (you should hear an audible click when it is properly inserted and securely seated). Verify the Power button depresses when pressed. Verify the battery contacts in headset battery holder and on the battery are clean and free of debris. Verify the battery is the correct type (only HME BAT70 batteries are valid, the battery is labeled on the back),
The headset does not pair	Verify the headset has a sufficiently charged battery and that the headset is powered on (the headset status LED illuminates). Hold the headset steady, centered, flush against the headset pairing ring. Movement and proximity can cause pairing failures.
The headset has no sound	Verify the headset is on. Verify the headset is paired. Verify the headset is within range of the transceiver. Press and hold the volume up button on the headset keypad, an audible beep gets louder as volume increases.
Headset communication is choppy or drops off	Headsets have an effective range based on the location of the RT7000 transceiver. Move the headset to within range of the transceiver. Large objects can also interrupt signal propagation. Try moving to a different location. Verify the headset has a charged battery.

Problem	Solution
Headset battery will not charge	Verify the charger is plugged in and on. Verify the battery is the correct type (BAT70). Verify the battery is docked correctly in the port (the battery is keyed so it can only be inserted one way. It should not be forced into the charging port). Verify the battery and charger contacts are clean and free from debris, contaminants, or obstructions. Verify battery is not dead. Batteries have lifespan, they will eventually die and will need to be replaced. The Base Station monitors battery charge cycles and informs you when to replace a battery. The AC70 needs to be within 10' (3 m) of the Base Station to monitor battery status.
RT7000 Transceiver not working	Verify that the Ethernet cable is good, and connected on both ends. The RT7000 Power LED illuminates when the Base Station is on. When disconnecting the RT7000 from a Base Station that is powered on, you must wait at least 30 seconds before reconnecting the RT7000 Ethernet cable. This allows the system time to sense the disconnection and turn power to the port off. Reconnecting to a live port can damage the circuitry. If a port is damaged, try connecting to another one.

VAIO TROUBLESHOOTING

Problem	Solution
Audio streaming is not flowing between NEXEO and the QSR Audio Service	• Verify that IB7000 version is 2.11.4 or higher and they are connected to the base. • Verify in VAIO Settings screen that VAIO is enabled, MQTT IP and PORT are set correctly, and RTSP Port is configured using the value used by the QSR Audio Service to connect to the Streaming Server. • Download VAIO logs and verify that MQTT is sending messages correctly (Heartbeat, Telemetry, Arrivals, etc). Then validate that the Streaming Server is up and running and that streaming client's connection is established. • Re-start the NEXEO base if MQTT or Streaming Server are not responding (not logging any information).
Audio streaming is not flowing between QSR Audio Service and NEXEO	• Verify in VAIO Settings screen that VAIO is enabled, and RTSP Port is configured using the value used by the QSR Audio Service to connect to the Streaming Server. • Validate that the IB7000 is connected to the base. • Validate that there is not headset connected to that lane with the microphone open. • Download VAIO logs and verify that the Streaming Server is up and running and that streaming client's connection is established. • Re-start the NEXEO base if Streaming Server is not responding (not logging any information)

Problem	Solution
Escalation tones are not playing	• Verify that there is a car present on the lane where the escalation should be played. • Verify that the escalation messages are present on the base, going to the Message Center, and validating that the 4 AOT Escalation messages are available. • Verify that the audio files associated with the escalation messages are also present on the base, going to the Message Center -> Audio Files tab, and validating that the 2 AOT Escalation files are there. • Download AOT logs and verify that the MQTT escalation message has been received on topic aot/request/auto-escalation/lane1 or aot/request/auto-escalation/lane2.
MQTT Telemetry and Ready messages are not being sent, while other messages are	• Download AOT logs and verify that the StreamingServer is up and running. • Send a re-start command via MQTT message from the QSR MQTT services. • Re-start the NEXEO base if Streaming Server is not responding (not logging any information).

LEDs

The System uses LEDs on components to indicate the status of the device.

LED	Description
AC70 Charger: RED LED 	A  (flashing red) LED indicates an unauthorized or unrecognized battery. Only HME approved (p/n BAT70) lithium-ion batteries can be used with your system.  Caution: Batteries not approved by HME will not charge properly and can cause damage to the system, including explosions with the potential to shock, inflict personal injury and/or start fires.  HME cares about the environment. Please check with your municipal laws, regulations, and guidelines for the proper disposal of dead lithium-ion batteries.
AC70 Charger: RED/YELLOW LED  	Flashing Red & Yellow (alternating)= Fault condition other than an unrecognized.

If you cannot resolve problems with the information presented here, please contact HME Technical Support at 1-800-848-4468.

TROUBLESHOOTING SCREENS

Perform basic diagnostics by tapping a tile on the Home screen to check a component’s status (see Fig. 15.1).




Fig. 15.1

Feature	Description
	Link: Checks that the post and base station are communicating. Loop Health: Checks that the vehicle detection loop is functioning properly. Vision AI: If your system is connected to a camera instead of a loop detector, Vision AI will appear instead of Loop Health. Speaker/Mic: Checks that the speaker and microphone for this lane are functioning properly.
	Traffic: Shows how many conversations are happening now. In Use: Shows how many headsets are currently in use. Status: Provides a headset’s status, whether functioning normally or not.
	Status: Indicates whether the transceiver is online. Remote Transceiver: This is the transceiver’s unique ID/serial number. Details: This indicates whether the transceiver is functioning properly.
	Battery Status of Ports 1 - 4: Each port tile tells you the status of the battery docked in it, whether it is charging, fully charged, dead, or unauthorized. Tap any port tile to expand for more details, including charging time, charge cycles, charging current, temperature, and serial number. Note: Battery charging status is also indicated by the LEDs on the AC70 battery charger. See “The Smart Battery Charger (AC70)” on page 17.
	Alert: System alerts can be viewed here. Alert details include name, date, and time.
	Network: This provides you with your LAN (Local Area Network) and HME CLOUD status.

Table 15.1

More detailed diagnostics can be found by going to System>Troubleshooting and tapping on System Diagnostics (see Fig. 15.2).





Fig. 15.2


What is this screen for? This screen provides system and component information to help you troubleshoot when issues arise. Tap the tab to open the drop-down list, then select the option you want to view. The information below covers the options in the drop-down list shown in Fig. 15.2.

System Diagnostics: Provides a breakdown of your system components and feedback on its health. Click on Base Station, Network, Audio, Speaker/Mic Posts, or AOT for details. See System Diagnostics Continued for more information.


Base Station: This provides you a profile of your Base Station, including serial number and firmware version. You can also restart the Base Station from here without having to disconnect and reconnect power. Press the Restart Base Station button, and this prompt appears suggesting doing so after service hours since the system may take several minutes to reboot.



Headsets: This lists all headsets associated with the Base Station. They are either connected (on) or disconnected (off). Click the More icon at the end of the row, then select "View Details" to see additional details for any listed headset. If "Remove" is selected from this menu, the headset is removed from the base station. A prompt will appear asking you to confirm. This feature is useful if a headset is no longer in use; it can help keep your listed headsets current and uncluttered. If a removed headset is reconnected, it will need to be paired again for the system to recognize it. The "Remove All Headsets" button removes all the listed headsets from the system. This will also initiate a system reboot, which can take several minutes. All headsets reintroduced will need to be paired with the system again to be used.



Speaker/Mic Posts: This provides a profile of your Speaker/Mic, including serial number and firmware version. The Restart Lane button reboots these components without disconnecting and reconnecting power. When you press the Restart Lane button, a prompt appears suggesting doing this after service hours since the system may take several minutes to reboot. The “Reset” button is not active and is reserved for use by the installer. The tooltip to the right of the “Reset” button asks you to call Technical Support at the listed number if you need to activate this button.



System Diagnostics continued: Valuable feedback on the health of each component can be found by clicking on any of the component options listed under System Diagnostics in Fig. 15.3 (i.e., Base Station, Network, Network Connectivity Test, Audio, Speaker/Mic Posts, and VAIO).




Fig. 15.3

Figure 15.4 is an example of what you see when you click on the Base Station option. This diagnostics section provides Technical Support with useful information when an issue occurs.




Fig. 15.4

Figure 15.5 is an example of what see when you click on the Network option. Scroll down further to view more details. This page also includes a Network Test, which can be performed by clicking on the Start Test button to the right. Fig. 15.6 shows this test with results displayed below the button.




Fig. 15.5

Figure 15.6 is an example of what see when the Network Connectivity Test is in progress.




Fig. 15.6

Figure 15.7 is an example of what see when you click on the Audio option. Scroll down further to view Lane 2.




Fig. 15.7

Figure 15.8 is an example of what see when you click on the Speaker/Mic Posts option.




Fig. 15.8

Figure 15.9 is an example of what see when you click on the VAIO option. VAIO is only available for customers with a NEXEO | Pro service. Also see “AOT/VAIO (Automated order taking/Voice AI ordering)” on page 28.




Fig. 15.9

ADDITIONAL TROUBLESHOOTING


If your system malfunctions, a red indicator on the HOME screen will alert you to where the problem is (see color-code definitions below). Then, try resetting the system component in question via the Base Station. For example, if the problem is the Speaker/Mic Posts:

1. Select SYSTEM from the sidebar menu.
2. Log in to the system.
3. Select the TROUBLESHOOTING tab.
4. Choose Speaker/Mic Posts from the drop-down list.
5. Tap the Restart Speaker/Mic Post button, then follow the prompt to reset.

Or, try resetting the system:

1. Select SYSTEM from the sidebar menu.
2. Log in to the system.
3. Select the TROUBLESHOOTING tab.
4. Choose Base Station from the drop-down list.
5. Tap the Restart Base Station button, then follow the prompt to reset.

Electrical Power Outage: If your system fails to function properly after an electrical power outage, power it off and unplug the AC power adapters from their outlets. Wait a few seconds, then plug them back in and power the system back on.




A red indicator like this one doesn't always indicate a failure. It may indicate that the feature/component is offline, inactive, or that something else requires corrective action. In this example, no headsets are detected; a headset must be turned on and paired for this marker to turn green. Tapping on the indicator will also reveal more details.



A red indicator like this one indicates a critical system failure and requires immediate attention. In this example, the transceiver has failed, which may be due to a disconnected or failed Ethernet cable or power loss. The system cannot function in this condition until the failure is resolved.



A yellow indicator indicates an intermediate or transitional state, such as scanning or an alert. When the Base Station is turned on, reset, or receives an upgrade, the transceiver indicator initially turns yellow as it scans the area for available channels, then turns green. This can take a few minutes.



A gray indicator like this one indicates that no AC70 Smart Battery Charger is sensed. Plug in the AC70 and position it within 10 feet (3 m) of the Base Station for it to turn green. Note: this marker is not red because the AC70 can function independently and does not require a Base Station connection to be functional.



A red exclamation mark like this indicates a new firmware update is available.



Visit System > Settings > Lane Setup to assign Speaker/Mic posts to lanes.

A red banner like this is a prompt requiring attention. This banner points to the item requiring attention. In this example, you are asked to go to the Settings tab on the SYSTEM screen. "Lane Settings" is found in the Settings drop-down list. Once there, you will notice that the Speaker Selection field prompts you to "Select One." For a single lane, there is only one entry to choose from, so select this entry. The Save button appears, click Save, and the speaker/Mic post is now assigned to the lane. The red banner on the Home page disappears.

FIRMWARE UPDATES

Red Exclamation Marks, like the one next to the SYSTEM icon in Fig. 15.9 indicate a feature or component that requires attention, such as a firmware update.




Fig. 15.10

1. Log in using your four-digit PIN and proceed to the SYSTEM screen. The Red Exclamation Mark is now also visible next to the UPDATES tab.
2. Tap on the UPDATES tab. In this example, the Base Station option requires attention. See Fig. 15.10.




Fig. 15.11

3. Select Base Station from the drop-down list (Fig. 15.11).
4. Tap the Update button that appears on the right (Fig. 15.12).





Fig. 15.12

5. A prompt appears informing you that the update will interrupt use of base the station and headset, and takes up to 15 minutes to complete. Tap/click the "Update Now" button to continue. The update begins and provides a progress status. The red exclamation mark also disappears when the update is initiated.



GLOSSARY OF TERMS

Attenuation: Attenuation is a telecommunications term that refers to a reduction in signal strength commonly occurring while transmitting analog or digital signals over long distances. Attenuation is historically measured in dB, but it can also be measured in terms of voltage.

Base Station: This is the central control unit for your system. The Base Station interfaces with all system components, including the Cloud. System features are configured and controlled here; headsets are also paired here.

ClearSound: This is a patented digital processing technology used to remove background noise from audio transmissions.

ClearSoundX: This is a proprietary AI algorithm that processes audio signals to remove background noise from audio transmissions.

CSV: Comma-Separated Value, is a file containing values separated by a delimiter, and formatted as a database table.

DHCP: Dynamic Host Configuration Protocol is a network management protocol used on UDP/IP networks. A DHCP server dynamically assigns an IP address and other configuration parameters to each device on a network so they can communicate with other IP networks.

Dropout: This is the term used when a vehicle is present at a detection point but not detected by the system.

DNS Server: Domain Name System Server is a directory of domain names with translated IP addresses.

Gateway: A device (usually a router) that connects one or more computers on a network to other networks.

Ghost Car/Vehicle: This is the term used when there are detection anomalies that occur when a vehicle is detected at one detection point but not detected at another. There are a few reasons why this can occur; for example, a vehicle drives over a detection point and then leaves the lane before reaching the next detection point or vice versa. Another example is if vehicles are too close together but are detected as one vehicle. Or, if a vehicle moves too quickly across one of several detection points to be detected.

Group/Crew Chat: This feature allows the headset user to converse with everyone in a group who shares the same position. It is the standard default mode for how this feature is used. Unified Crew Chat is another mode that allows the headset user to converse with everyone, regardless of their assigned position. Everyone, in every position, becomes part of the group and can converse. This mode is off by default and can be enabled only at the request of a brand administrator. When Unified Crew Chat is enabled, standard mode is automatically turned off.

Headset: This is the device worn by your crew/staff and used for 2-way communication between crew members and customers. It consists of an earpiece with keypad and a boom microphone. The system uses two headset models: HS7000 and HS7100.

HME CLOUD: This is a remote server used by your system. It allows your system to access and store data via the internet. It also provides access to other systems in your network connected to the HME CLOUD.

IP Address: Internet Protocol Address. A unique computer address that some electronic devices (such as computers or routers) use to identify and communicate with each other on a network.

NTP: Network Time Protocol is a networking protocol for clock synchronization between computer systems and is intended to synchronize all participating systems to within a few milliseconds of local standard time or Coordinated Universal Time (UTC)

Pairing: This is an initiation process required to establish a wireless connection between two or more devices allowing them to find, recognize and communicate with each other. It pairs a device to the system's control unit; headsets for example must be paired with the Base Station before they can be used. They need to be paired every time they are put back into service if they have been logged out of the system when not in use.

Registration: This is a one-time function that registers a new device with an existing system. Headsets when used for the first time are registered at the base station. This happens automatically with the initial pairing. Once registered, the headset becomes a part of the system even though they still need to be paired with each use.

Registration Key: This is unique identifying key generated when a new store is initiated by the sales department. It allows HME products to be linked to a specific store ensuring easier installations with reduced errors while also enhancing service management.

Radio/Remote Transceiver: Sometimes referred to as RFP (Radio Fixed Part) is the combined radio/antenna system that facilitates wireless communication between headsets and the base station. At least one is required per store but up to four can be installed as range extenders for larger premises. A radio transceiver can accommodate ten chat channels and ten private communication channels.

Run-on: This is the term used for a vehicle that has departed from a detection point but is still sensed as being present.

Speaker: These are speakers in addition to the headset speakers, providing another source of audio for inside or outside the store. Speakers are installed externally at menu boards to communicate with customers and can also be installed inside the store enabling a manager to address employees such as those without headsets.

Subnet Mask: Splits the network into a series of subgroups or subnets to speed up the delivery of data by the routers.

System Version: This is a version suite, a collective of all device firmwares under a single system version.

Telemetry: In general, it is defined as the automated collection and transmission of data from a remote device or system to another system for monitoring, analysis, or management purposes. For NEXEO it is a feature that collects and transmits system status and settings information to connected monitoring systems. Telemetry reports the status of headsets, speakers and microphones, VAIO data, loop health, and overall system health through the MQTT broker, helping brands maintain an up-to-date view of system operation. Status messages are sent at a minimum interval of 10 seconds to prevent network overload.

Tooltip: This is a pop-up tip box dialog that provides information or help for a feature, term, link, button or icon. Hovering over or tapping on an element that has a tooltip associated with it, triggers the tooltip to appear. The tooltip caret points to or is centered on the element that triggered it.

Web Server Port: This is the unique network port number used by NEXEO to communicate over the network it is connected to.

VAIO GLOSSARY OF TERMS

ASR: This refers to the process of automatic speech recognition, often used to transform speech to text (STT) for further analysis and interpretation.

BOT: An AI service helping employees or customers. The Bot Order Taker helps customers with orders while the Employee Bot assists employees with other in-store functions.

BOT Escalation: When the BOT is not able to understand the intention of the QSR customer or the language spoken by them is not supported, it sends an escalation request, to indicate the crew members that assistance is needed.

Crew-Takeover: When a crew member taps 1 or 2 on their headset keypad, a crew takeover signal is sent to the BOT to indicate that the order will be taken by the restaurant crew member.

MQTT: Message Queuing Telemetry Transport, this is a lightweight messaging protocol designed for efficient communication in environments with limited bandwidth and potentially unreliable network conditions. It operates on a publish/subscribe messaging model, making it ideal for Internet of Things (IoT) applications where devices need to exchange data efficiently and reliably.

RTSP: The Real Time Streaming Protocol is a network control protocol designed for use in entertainment and communications systems to control streaming media servers.

Streaming Server: This is a component that runs inside the NEXEO base as a service, and it mainly listens to connections from clients on a specific port (RTSP Port), has the capability to send and receive audio streams, and provides the ability to control the media transmissions via commands.

TTS: This refers to the process of transforming text to speech (TTS), used to produce audio from a text script.

SPECIFICATIONS

BS7000	
Dimensions	7.62" H x 12.579" W x 3.669" D (193.55 x 319.51 x 93.19 mm)
Weight	3.5 lb (1.59 kg)
Power Supply	Input Voltage: 100 - 240 VAC nominal Output Voltage: 48 VDC Current: 1.88 A Power: 90 W
LAN	Gbit Ethernet
Front Panel	LCD type: 800x480 TFT w/ capacitive touch
Rear Panel	RJ45 (x5), USB type C, USB type A, PCBA mounted power supply & component headers
Temperature	Operating Temperature range: 0°C (+32°F) to +50°C (+122°F).
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

HS7000 & HS7100 Headset	
Dimensions	5.2" H x 5.2" W x 2.4" D (132.1 x 132.1 x 61 mm) with boom excluded 9.2" H x 5.2" W x 2.4" D (234.4 x 132.1 x 61 mm) with boom extended down
Weight (HS7100)	3.17 oz (90 g) without battery, 3.91 (111 g) with battery (3.67 oz/104 g for HS7000)
Power Supply	Voltage: 3.7 VDC, powered from a rechargeable Lithium-ion battery
Sleep Mode (HS7100)	Inactivity time to sleep mode: 90 seconds after power on, 10 minutes after use
Frequency Range	Audio: 100 Hz to 7.48 kHz
Wireless	Main Radio: 5.180 GHz – 5.8525 GHz
Power, Watts HS7100	Nominal Power with listening only: 0.318 W, Dedicated: 0.4 W, Sleep: 0.005 W
Power, Watts HS7000	Nominal Power with listening only: 0.314 W, Dedicated: 0.4 W
Keypad type	Touch Sense
Temperature	Operating Temperature range: 0°C (32°F) to +50°C (+122°F) Storage Temperature range: -10°C (14°F) to +80°C (+176°F)
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

AC70	
Dimensions	5.09" L x 3.64" W x 1.84" H (129.2 x 92.4 x 46.7 mm)
Weight	5.97 oz (169.19 g)
Power Supply	Input Voltage: 100 - 240 VAC nominal Output Voltage: 5 V; 4 A. Charge Output: ~ 3 W per port MTBF (min.): 300,000 hours demonstrated
Wireless	Wireless PAN, Short Range Data Link
Front Panel	Four charging ports for BAT70 LED type: 4 x RGB, for port/battery charging status
Side Panel	Four storage ports for BAT70 (Storage ports do not charge)
Temperature	Operating Temperature range: 32°F - +104°F (0°C - +40°C) Storage: -40°F to +176°F (-40°C to +80°C) Humidity: 0 - 95%, non-condensing
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

RT7000

Dimensions	6.705" H x 7.157" W x 1.56" D (170.31 x 181.79 x 39.62 mm)
Weight	13.95 oz (395.6 g)
Power Supply	Voltage: 48 VDC (powered from BS7000). Current: 60 mA pk-pk @ 48 V
LAN	Ethernet wired connection to Base Station - AES/EBU interface
Frequency Range	Main Radio: 5.180 GHz – 5.8525 GHz
Power	2.88 W
Front Panel	LED type: 5 x RGB, one for power and 4 for port indication
Rear Panel	RJ45 port
Temperature	Operating Temperature range: -25°C (-13°F) to +60°C (+140°F).
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

IB7000

Dimensions (IB only)	5.68" H x 5.68" W x 2.05" D (144.3 x 144.3 x 52.1 mm)
Dimensions (Cover only)	6.79" H x 5.85" W x 2.22" D (172.3 x 148.6 x 56.4 mm)
Dimensions: IB with Cover	6.79" H x 5.85" W x 2.83" D (172.3 x 148.6 x 71.6 mm)
Weight: IB with Cover	19.2 oz (543 g). IB = 14.4 oz (408.2 g), cover = 4.8 oz (135 g)
Power Supply	Voltage: 48 VDC (powered from BS7000) Current: 0.331 A (max start up)
Frequency Range	Audio: 100 Hz to 7.4 kHz Powerline network over 48 VDC: 2 MHz – 67.5 MHz
Power	Nominal power with no audio: 5.2 W Maximum power at maximum volume: 27 W
Front Panel	Two adhesive strips for mounting to a vertical surface
Rear Panel	Phoenix connector type headers (includes speaker output and analog DM5 microphone input)
Wireless	N/A
Temperature	Operating Temperature range: -25°C (-13°F) to +60°C (+140°F)
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

SS7000

Dimensions	3.92" H x 5.76" W x 3.44" D (99.6 x 146.3 x 87.4 mm)
Weight	1.14 lb (492.6g)
Power Supply	Voltage: 48 VDC, powered from BS7000
Frequency Range	Audio: 100 Hz to 7.4 kHz
Power	15 W, 8 Ω
Rear Panel	Phoenix connector type headers
Wireless	N/A
Temperature	Operating Temperature range: -25°C (-13°F) to +60°C (+140°F)
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

SP10	Speaker
Dimensions	5.62" H x 5.62" W x 4.5" D (142.8 x 142.8 x 114.3 mm)
Dimensions with foam gasket	5.62" H x 5.62" W x 4.75" D (142.8 x 142.8 x 120.6 mm)
Weight	2.55 lb (1.16 kg)
Power	15 W
Impedance	8 Ω
Temperature	Operating Temperature range: -22°F to +140°F (-30°C to +60°C)

DM5	Microphone
Dimensions	2.81" H x 2.81" W x 1.78" D (71.5 x 71.5 x 45.1 mm)
Weight	4.37 oz (123.9 g)
Microphone Type	Electronic
Impedance	200 Ω
Temperature	Operating Temperature range: -22°F to +140°F (-30°C to +60°C)

SP7000	Speaker/IB
Dimensions	5.9" H x 5.9" W x 4.55" D (149.9 x 149.9 x 115.6 mm)
Weight	2.44 lb (1.11 kg)
Power Supply	Voltage: 48 VDC (powered from BS7000). Current: 0.331 A (max start up)
Frequency Range	Audio: 100 Hz to 7.4 kHz. Powerline network over 48 VDC: 2 MHz – 67.5 MHz
Power	Nominal power with no audio: 5.2 W. Maximum power at maximum volume: 27 W
Front Panel	Speaker: 15 W, 8 Ω
Rear Panel	Phoenix connector type headers (includes analog DM5 microphone input)
Wireless	N/A
Temperature	Operating Temperature range: -25°C (-13°F) to +65°C (+149°F)
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online

Optional Accessory (only available for the US and Canadian market)

TI7000	Telephone Interface
Dimensions	6.6" L x 4.5" W x 1.8" H (168 x 113 x 46 mm)
Weight	7.8 oz (221 g)
Power Supply	Voltage: 12 VDC, powered from BS7000
Panel	RJ11 and RJ45 connector type ports and two on/off switches
Wireless	N/A
Temperature	Operating Temperature range: -25°C (-13°F) and +45°C (+113°F)
Compliance	See NEXEO HDX - Regulatory, Compliance, and Safety Guide online



A copy of this guide and much more including Regulatory, Compliance,
and Safety information can be found by scanning this QR code or going to:
<https://www.hme.com/qsr/drive-thru-user-manuals/>

© 2026 HM Electronics, Inc.
*The HME logo and product names are registered trademarks of HM Electronics, Inc.
All rights reserved.*