

BELT-PAC AND HEADSET OPERATION:

- PWR** Power on/off
- ▲** Headset volume up
- ▼** Headset volume down
- A1** or **A2** Talk to customers
- B** Talk to crew



Mode	One-Touch Hands Free	Push To Talk	Auto Hands Free
Mode Setup	With power off Press ▲ + B + PWR Release buttons	With power off Press ▼ + B + PWR Release buttons	With power off Press ▲ + (A1 or A2) + PWR (A1 for Single Lane or Lane 1) (A2 for Lane 2) Release buttons
	<i>In this mode, press and release A1 or A2 button to talk to customer</i>	<i>In this mode, press and hold A1 or A2 button to talk to customer</i>	<i>In this mode, talk to customer without pressing buttons</i>
Single Lane Operation	Customer arrives Alert tone in headset Touch-Release A1 or A2 Speak/Listen to customer Touch-Release A1 or A2 or B Communication ends	Customer arrives Alert tone in headset Press & hold A1 or A2 Speak to customer Release to listen	Customer arrives Alert tone in headset Speak/Listen to customer Touch-Release A1 or A2 or B Communication ends
	<i>In Tandem operations, Order Taker #1 uses the A1 button for customers at order point #1 and Order Taker #2 uses the A2 button for customers at order point #2</i>		<i>In Tandem operations, only Order Taker #1 can operate in the Auto Hands Free mode</i>
Dual Lane Operation	Customer arrives Alert tone in headset 1 beep = connected lane 2 beeps = other lane Touch-Release A1 for Lane 1 Touch-Release A2 for Lane 2 Touch-Release opposite button to change lanes Speak/Listen to customer Touch-Release A1/A2 or B Communication ends	Customer arrives Alert tone in headset 1 beep = connected lane 2 beeps = other lane Press & hold A1 for Lane 1 Press & hold A2 for Lane 2 Speak to customer Release A1 / A2 to listen	Customer arrives Alert tone in headset 1 beep = connected lane 2 beeps = other lane Speak/Listen to customer Touch-Release A1 or A2 or B Communication ends

COMMUNICATOR STATUS: With power off — Press **A2 + ▼ + PWR**

CHANGE BATTERY:

If you hear “Battery low” or “Change battery” in your headset;

- Slide battery-release latch in direction of arrow
- Place battery in battery-charger port for recharging
- Install fully charged battery in Belt-Pac or headset



벨트 부착기와 헤드셋 작동법:

- 스위치 켜기/끄기
- 헤드셋 볼륨 높이기
- 헤드셋 볼륨 낮추기
- 나 고객에게 말하기
- 다른 직원과 말하기



모드	원 터치 핸드 프리 모드	누르고 말하기 모드	자동 핸드 프리 모드
모드 설치	스위치를 끈 채 + + 를 누른다 버튼을 놓는다	스위치를 끈 채 + + 를 누른다 버튼을 놓는다	스위치를 끈 채 + (혹은) + 를 누른다 (A1 은 한 줄 혹은 첫번째 줄 용도) (A2 는 두번째 줄 용도) 버튼을 놓는다
	이 모드에서는 A1 혹은 A2 를 눌렀다가 놓은 다음 고객과 말한다	이 모드에서는 A1 혹은 A2 를 누른 상태로 고객과 말한다	이 모드에서는 아무것도 누르지 않은 채 고객과 말한다
한 줄 작동법	고객이 도착하면 헤드셋에서 신호음이 울린다 혹은 를 누른 다음 놓는다 고객과 이야기한다 혹은 혹은 를 눌렀다 놓는다 통화가 끝난다	고객이 도착하면 헤드셋에서 신호음이 울린다 혹은 를 계속 누른다 고객에게 말한다 들을 때는 버튼을 놓는다	고객이 도착하면 헤드셋에서 신호음이 울린다 고객과 이야기한다 혹은 혹은 를 눌렀다 놓는다 통화가 끝난다
	새로로 일렬이 되어 작동할 때, 주문 받는 사람 #1 은 주문하는 고객 #1 과 통화하기 위해 A1 버튼을 이용하고, 주문 받는 사람 #2 는 주문하는 고객 #2 와 통화하기 위해 A2 버튼을 이용한다		새로로 일렬이 되어 작동할 때는 단지 주문 받는 사람 #1 만이 자동 핸드 프리 모드를 사용할 수 있다
두 줄 작동법	고객이 도착하면 헤드셋에서 신호음이 울린다 1 번 신호음 = 현재 연결된 줄 2 번 신호음 = 다른 줄 첫번째 줄 용도로 을 눌렀다 놓는다 두번째 줄 용도로 를 눌렀다 놓는다 줄을 바꾸려면 다른버튼을 눌렀다 놓는다 고객과 이야기한다 / 혹은 를 눌렀다 놓는다 통화가 끝난다	고객이 도착하면 헤드셋에서 신호음이 울린다 1 번 신호음 = 현재 연결된 줄 2 번 신호음 = 다른 줄 첫번째 줄 용도로 를 계속 누른다 두번째 줄 용도로 를 계속 누른다 고객에게 말한다 들을 때는 / 를 놓는다	고객이 도착하면 헤드셋에서 신호음이 울린다 1 번 신호음 = 현재 연결된 줄 2 번 신호음 = 다른 줄 고객과 이야기한다 혹은 혹은 를 눌렀다 놓는다 통화가 끝난다

통화 상태 점검: 스위치를 끈 채로 - + + 를 누른다

бат데리 바꾸기:

헤드셋에서 “бат데리 낮음 (Battery low)” 혹은 “бат데리를 바꾸세요 (Change battery)”라고 들리면

- бат데리 제거 고리를 화살표 방향으로 민다
- бат데리를 бат데리 충전기에 넣고 재충전한다
- 충분히 충전된 бат데리를 벨트 부착기나 헤드셋에 넣는다

