

### BELT-PAC OPERATION:

- PWR** Power on/off
- ▲** Headset volume up
- ▼** Headset volume down
- A1** or **A2** Select & talk to next customer
- B** Disconnect from customer



### Push To Talk

### One-Touch Hands Free

*Mode Setup*

**With power off**  
**Press ▼ + B + PWR**  
**Release buttons**

**With power off**  
**Press ▲ + B + PWR**  
**Release buttons**

*In this mode, press and hold A1 or A2 button to talk to customer*

*In this mode, press and release A1 or A2 button to talk to customer*

*Routine Operation*

**Customer arrives**  
**You hear alert sound in headset**  
**Double beeps for drive-up stalls**  
**Single beeps for drive-thru lane**

**Press & hold A1 or A2**  
**You hear stall number or “drive-thru” in headset**

**Speak/Listen to customer**

**Release A1 or A2 to stop talking to customer**

**Press & release B to end communication with customer**

**Customer arrives**  
**You hear alert sound in headset**  
**Double beeps for drive-up stalls**  
**Single beeps for drive-thru lane**

**Press & release A1 or A2**  
**You hear stall number or “drive-thru” in headset**

**Speak/Listen to customer**

**Press & release B to end communication with customer**

**If there are more customers waiting to be served, you will automatically be alerted for the customer who pushed the call button first. Customers in the drive-thru lane will be served ahead of customers in drive-up stalls.**

### CHANGE BATTERY:

- If you hear “Battery low” or “Change battery” in your headset;**
- Slide battery-release latch in direction of arrow
  - Place battery in battery-charger port for recharging
  - Install fully charged battery in Belt-Pac



FUNCIONAMIENTO Y OPERACIÓN  
DEL COMUNICADOR (COM6000):

- PWR** Encender/Apagar
- ▲** + volumen
- ▼** - volumen
- A1** o **A2** Para seleccionar y hablar con clientes
- B** Para terminar la comunicación con el cliente



*Oprimir para hablar  
y soltar para escuchar*

*Manos libres con un toque*

## Fijar Modo

**Estando apagado**  
Oprima **▼** + **B** + **PWR**  
Suelte los botones

**Estando apagado**  
Oprima **▲** + **B** + **PWR**  
Suelte los botones

*En este modo,  
mantener oprimido A1 o A2  
para hablar con el cliente*

*En este modo,  
oprimir y soltar botón A1 o A2  
para hablar con el cliente*

## Operación

**Al llegar un cliente**  
Se escucha el tono de alerta en el audífono

- el tono doble es para vehículos estacionados
- el tono sencillo es para vehículos en la línea del Drive-Thru

Dejar oprimido **A1** o **A2**  
Escucharas él numero del estacionamiento o la palabra "Drive-Thru" en el audífono

Hablar y escuchar al cliente  
Soltar **A1** o **A2** para suspender la comunicación con el cliente  
Oprimir y soltar el botón **B** para terminar la comunicación con el cliente

**Al llegar un cliente**  
Se escucha el tono de alerta en el audífono

- el tono doble es para vehículos estacionados
- el tono sencillo es para vehículos en la línea del Drive-Thru

Oprimir y soltar el botón **A1** o **A2**  
Escucharas él numero del estacionamiento o la palabra "Drive-Thru" en el audífono

Hablar y escuchar al cliente  
Oprimir y soltar el botón **B** para terminar la comunicación con el cliente

Si hay mas clientes esperando, un tono de alerta te indicara automáticamente cual es el siguiente cliente que oprimó el botón para ser atendido. Los clientes en el Drive-Thru tendrán prioridad para ser atendidos sobre los clientes estacionados.

## CAMBIO DE BATERÍA:

Si usted escucha "Batería baja" o "Cambie la batería" en su audífono, haga lo siguiente:

- Deslice la junta de la batería en dirección de la flecha
- Coloque la batería en el cargador de baterías para recargarla
- Instale la batería completamente cargada en el comunicador (COM6000)

