




Headset Interface Cable

INSTALLATION INSTRUCTIONS

The Headset Interface Cable allows most hardwired intercom headset XLR jacks to directly interface with the DX121 Base Station for instant, wireless communication. The DX121 System is designed to take the place of most standard broadcast dynamic microphone headsets requiring a 4-Pin XLR male or female connector.

Connect the four wires from the cable to the 10-pin connector that was provided with your DX121 Base Station, and plug it into the Headset/4-Wire receptacle as shown below. Plug the connector at the other end of the cable into an RTS® or Clear-Com® system.

DX121 Base Station connection to RTS® system



DX121 Base Station connection to Clear-Com® system

