

# CHANGING DAYPARTS ON THE SYS30 TIMER

1. Press the **SET-UP DAYPARTS & SHIFTS** key. If you have a lockout code setup in the programming, enter the lockout code and press **ENTER**.
2. Press + or - key until the following screen appears:

Set Up Dayparts/  
Shifts Menus:  
**DAYPARTS**  
Press + or - & ENTER

3. Press **ENTER** key to get the following screen:

Set Up Dayparts (p1):  
01=07:00A    02=11:00A  
03=02:00P    04=05:00P  
Press + or - & ENTER

- a. Press the number keys to enter the BEGINNING time for the first Daypart, DO NOT enter an end time for ANY Daypart;
  - b. Press the + or - key to choose A (AM) or P (PM) for each Daypart;
  - c. Press **ENTER** key to move to the next Daypart or to skip any field you do not wish to change;
  - d. Repeat steps 3.a and 3.b for each Daypart;
  - e. Press 00:00 for the beginning time to turn any Daypart OFF;
  - f. A maximum of 12 Dayparts may be entered.
4. Press **EXIT** key twice to return to the main display.