

PRINTING SYSTEM 30 SETTINGS

To Print All Settings:

1. Press the SET UP SYSTEM key. Screen Should show:

Set Up System Menus:
DRIVE-THRU MANAGER

Press + or - & ENTER

2. Press + or - until the following screen appears

Set Up System Menus:
PRINT PROGRAMMING

Press + or - & ENTER

3. Press ENTER key to get the following screen:

Print Programming
Print: SYSTEM
Setup Listing
Press + or - & ENTER

4. Press + or - until the following screen appears:

Print Programming
Print: ALL
Setup Listing
Press + or - & ENTER

5. Press ENTER key to begin printing

6. When report is finished, press EXIT to return to standby screen

