

MANUALLY PRINT A REPORT FROM THE SYS20 TIMER

- 1 Push the **ENTER** key on the keypad. If you have a lockout code setup in the programming, enter the lockout code first. The next display on the LCD display that appears as shown here:



```
04/26/05 06:30:54
> Enter command or ESC <
```

- 2 Push the **REPORT** key. Then next display on the LCD display that appears as shown here:



```
04/26/05 06:30:54
> On Demand Reports
(1-9) or 0 = Done: 0 <
```

- 3 Push the number key for the report you wish to run from the list below:

Report Number	Description
1	Every Car Report
2	Any Hour Report
3	Any Daypart Report
4	Any Day Report
5	Any Week Report
6	Any Period Report
7	Any Month Report
8	Year-to-date Report
9	Not used