System 900

Wireless Audio System

Operating Instructions (For Full-Duplex and Half-Duplex Operations)

14110 Stowe Drive, Poway, CA 92064 USA Phone: 1-800-848-4468 Fax: (858) 552-0172



Table of Contents

Ι.	GF	NFF	RAL		
II.			MENT FUNCTIONS AND USE		
	A. Base Station				
	B.		0M900CC COMMUNICATOR [®]		
	D.		Controls and Connector		
		1.			
		2.	Wearing the COM900CC COMMUNICATOR [®]		
		3.	Charging the COM900CC Batteries		
	C.	CC	DM900BP COMMUNICATOR [®]		
		1.	Controls and Connector		
		2.	Wearing the COM900BP COMMUNICATOR [®]		
		3.	Charging the COM900BP Batteries		
	D.	СС	0M930BP COMMUNICATOR [®] 12		
		1.	Communicator Controls 12		
		2.	Wearing the COM930BP COMMUNICATOR [®]		
		3.	Charging the COM930BP Batteries 14		
III.	SY	STE	M 900 OPERATION		
	Α.	СС	MMUNICATOR [®] Operation		
	В.	Sp	eed-Team Drive-Thru Operation		
	C.	Re	mote Display Operation		
	D. Message Repeater Operation 19				
IV.	HC	T W	O CARE FOR THE EQUIPMENT		
	А.	Th	e COMMUNICATOR [®]		
	В.		e Battery Charger		
V.	IN		SE OF PROBLEMS		
VI.	SP	FCI	FICATIONS		
VII.			SSORIES AND OPTIONAL EQUIPMENT		
VIII.			OTICE		
V 111.	10	~ 14			

List of Figures

Figure	Title	Page
1	Base Station	. 1
2	COM900CC COMMUNICATOR [®]	. 2
3	COM900CC control buttons	. 2
4	Cable connectors showing matching pin positions	. 2
5	Correct wearing of the COM900CC	. 3
6	Remove and replace Communicator battery	. 4
7	Inserting a battery into the AC900 Battery Charger	. 4
8	Battery charging indicator lights	. 5
9	Battery going into AC900 storage port	. 5
10	COM900CC battery charging in the AC910 Battery Charger	. 6
11	COM900BP COMMUNICATOR [®]	. 7
12	COM900BP controls, connector and indicator light	. 7
13	Plug the headset-cable connector into the cable receptacle	. 8
14	Insert belt through belt loop on back of Communicator pouch	. 8
15	Correct wearing of Communicator headset	. 8
16	Installing the battery	. 9
17	Opening the battery compartment	. 9
18	AC420 Battery Charger shown with a properly installed battery	10
19	COM900BP battery charging in the AC910 Battery Charger	11
20	COM930BP COMMUNICATOR [®]	12
21	Communicator controls	12
22	Communicator transceiver in pouch	13
23	Correct wearing of the HS30 Headset	13
24	Installing the COM930BP battery	14
25	Opening the COM930BP battery compartment	14
26	HS30 Headset	15
27	HS30 Headset transceiver	15
28	AC30 Battery Charger	16
29	AC930 Battery Charger	17
30	Base station circuit boards	23

In the event of an electrical power outage

such as from a lightning storm or power generator failure, if you experience problems with your HME equipment after the electricity comes on again, unplug the AC power adapters from their electrical outlets, then plug them back in.

I. GENERAL

The System 900 is a wireless audio system primarily for use at quick-service restaurants.

II. EQUIPMENT FUNCTIONS AND USE

A. Base Station

Front -

System indicator lights

- **POWER light** is on when the base station has power.
- I MESSAGE RECORD light is on RED when the base station is ready to record message #1 for the message repeater, and blinking RED while message #1 is being recorded. It is on GREEN when the base station is ready to record message #2 for the message repeater, and blinking GREEN while message #2 is being recorded. The MESSAGE REPEATER button must be pushed IN.
- **RECEIVE light** is used only for troubleshooting, but is also on during channel-A and channel-B transmissions.
- ! "A" light is on during channel-A transmission.
- **"B" light** is on during channel-B transmission.
- **VEHICLE light** is on when a vehicle is present in the drive-thru lane or when the system is in vehicle-detect override.

Bottom -

- **PUSH FOR RECORD MODE button**; must be pushed IN and released once to prepare the base station to record message #1 for the message repeater, or pushed IN and released twice to record message #2.
- **MESSAGE REPEATER button**; must be pushed IN to use the message repeater, OUT when the message repeater is not being used.
- **SPEED TEAM button**; must be pushed IN for speed-team operation, OUT for normal drive-thru operation
- I VEHICLE DETECTOR button; to override a vehicle detector, push and leave IN: to reset vehicle detector, push IN and leave In for 5 seconds, then push again and leave OUT for normal vehicle detection.

Left Side -

WIRED/WIRELESS button; must be OUT when using the wireless System 900, IN when using a wired backup system.




Figure 1. Base station

B. COM900CC COMMUNICATOR®

The COM900CC COMMUNICATOR[®] consists of a transceiver and a lightweight headset designed to be used with the HME Wireless Drive-Thru Audio System 900. The transceiver is worn around the collar, and the headset plugs into a connector on the transceiver unit.





1. Controls and Connectors

Plug the headset cable connector into the cable connector on the COM900CC collar




Figure 3. COM900CC control buttons.

unit, as shown in Figure 4. Be careful to correctly match the positions of the pins inside the connector.




Figure 4. Cable connectors showing matching pin positions

2. Wearing the COM900CC COMMUNICATOR®

- Place the Communicator collar unit around your neck and put the headset on your head as shown in Figure 5.
- ! Adjust the headset band so it rests securely on top of your head, with the microphone to the side of your mouth.
- ! Adjust the Communicator so it fits comfortably around your collar.
- ! Fasten the clothing clips to your collar as shown in Figure 5.




Figure 5. Correct wearing of the COM900CC

3. Charging the COM900CC Batteries

When there are good batteries in the COMMUNICATOR[®] and the power is on, the red light above the power (PWR) button will be lit. This light only indicates the power is on. It does not indicate how much power is left in the batteries. As the batteries weaken during routine use, you will hear "Low battery" in the earpiece, indicating the batteries need to be replaced. When this happens, remove both batteries from the Communicator as shown in Figure 6. Place both batteries in the AC900 Battery Charger for recharging. Refer to Figures 7 through 9. Replace the batteries in the Communicator with fresh, fully charged batteries. Typical battery life with normal use is 8 to 10 hours.

CAUTION: To prevent damage, turn Communicator OFF before removing or installing batteries.



Installing and Removing Communicator Batteries:

Figure 6. Remove and replace Communicator battery

Charging COM900CC Batteries in the AC900 Battery Charger:

Place up to four COM900CC batteries in the charger for charging at a time. See Figure 7. The red Charging light, adjacent to a battery being charged will go on and remain on while the battery is charging. Routine battery charging takes up to 3 hours.

NOTE: The COM900CC uses "smart batteries." That means each battery maintains a history of the





Figure 7. Inserting a battery into the AC900 Battery Charger

number of times it has been charged. The AC900 Battery Charger reads and updates this history each time a battery is charged. This information is used to automatically initiate conditioning cycles, which improve the battery's performance and prolong its life. A conditioning cycle consists of a complete discharge before a battery is charged. This happens each time the battery history indicates it has been charged 10 times since the last conditioning cycle. While a battery is discharging, the red Charging light next to it will blink on and off at 2-second intervals. The conditioning cycle takes up to 6 hours.




When a battery is fully charged and ready for use, its red "Charging" light will go off and the green "Ready" light next to it will go on.

Figure 8.

Battery charging indicator lights

CAUTION: Do not remove batteries from the charger until the green READY light is lit, or the charger will reset and the charge cycle will begin again.




To remove a fully charged battery from the battery charger, push the battery from the end near the status lights.

Store fully charged batteries in the storage ports on the right side of charger until you need them, as shown in Figure 9.

Figure 9. Battery going into AC900 storage port

CHARGING LIGHT STATUS TABLE – WITH BATTERY INSERTED				
CHARGING LIGHT	WHAT IT MEANS	WHAT TO DO		
Red blinks: 2 times quick - 3 seconds off	Discharge error	Either the battery or the charger has a problem. Mark the battery and		
Red blinks: 3 times quick - 3 seconds off	Charging error	retry in a different charging port. The battery is faulty if it has the same problem in a different port		
Red blinks: 4 times quick - 2 seconds off	Low-battery error	AND a known-good battery passes in the same ports. The charger circuitry is faulty if a known-good		
Red blinks: 5 times quick - 2 seconds off	Charging error	BATTERY fails in the same ports.		
Green blinks: 2 second on - 2 second off	Read-write error			
Green blinks: 3 times quick - 3 seconds on	Memory full			
Red and Green blink alternately	Authentication error			

Charging COM900CC batteries in the AC910 Battery Charger:



COM900CC battery charging in the AC910 Battery Charger

Place up to four COM900CC batteries in the charger for charging at a time. The red Charging light, adjacent to a battery being charged will blink for a few seconds when the battery is placed in the charger, then will go on and remain on while the battery is charging.


NOTE: The COM900CC uses "smart batteries." That means each battery will retain charging information that will cause it to automatically discharge completely before being recharged, every tenth time it is placed in the charger. This will improve the battery's performance and life. While a battery is discharging, its red Charging light will blink on and off at 2 second intervals.

When the battery is fully charged and ready for use, the red light will go off and the green Ready light adjacent to the battery will go on.


To remove fully charged batteries from the battery charger, push the battery from the end near the status lights. Store fully charged batteries in the storage ports until you need them.

C. COM900BP COMMUNICATOR®

The COM900BP COMMUNICATOR[®] consists of a transceiver and a lightweight headset designed to be used with the HME Wireless Drive-Thru Audio System 900. The Communicator is worn around the user's waist, and the headset plugs into a connector on the transceiverunit.







1. Controls and Connector

Figure 12. COM900BP controls, connector and indicator light

- 1 POWER ON and OFF buttons: turns Communicator on and off.
- 2 VOLUME buttons: adjust listening level in earpiece.
- 3 Power-on light: lights when power goes on, and remains lit until battery needs replacing or Communicator is turned off. The power-on light blinks when transmitting on "A" or "B" channel.
- 4 Button A: allows two-way communication when pushed and held; when it is released, the user can listen only.
- 5 Button B: must be pushed and held to talk, and released to listen.
- 6 Button C: used to change lanes in dual-lane operations.
- 7 5-pin DIN receptacle: receptacle for earpiece/microphone cable connector.
- 8 Battery: provides power for the wireless belt-pac Communicator.
- 9 Battery release latch: slides to release battery for removal, and snaps in place when a battery is inserted to secure battery in Communicator.

2. Wearing the COM900BP COMMUNICATOR®

Plug the headset-cable connector into the receptacle on the Communicator transceiver as shown in Figure 13. The connector is keyed so it can only be inserted in the correct position, with the cord extending downward. After plugging the connec-tor into the receptacle, cover it with the connector cover flap shown on Figure 13, and fasten the snap securely in place. Loosen the snap on the cord protection flap and resnap it with the flap over the cord.





Figure 13. Plug the headset-cable connector into the cable receptacle


Belt-Pac (Pouch with Belt Loop):


If your Communicator transceiver has a belt loop on the back of its pouch, insert a belt through the loop on back of the pouch as shown in Figure 14, and fasten the belt securely around your waist. The transceiver can be worn on your right or left side.

Belt-Pac (Pouch with Belt Clip):

If your Communicator transceiver has a belt clip on the back of its pouch, simply squeeze open the belt clip and slide it over your belt or waist band. The transceiver can be worn on your right or left side.







Correct wearing of the Communicator headset

Put the headset on your head and clip one of the clothing clips to your collar as shown in Figure 15. Clip the other clothing clip to the back of your shirt, above your waist. Position the microphone approximately 2 inches (50.8 mm) from your mouth.

3. Charging the COM900BP Batteries

When a good battery is in the COMMUNICATOR[®] and the power is on, the red light on top of the unit will be lit. This light only indicates the power is on. It does not indicate how much power is left in the battery. As a battery weakens during routine use, you will hear "Low battery" in the earpiece, indicating the battery needs to be replaced. Typical battery life with normal use is 8 to 10 hours.

CAUTION: To prevent damage, turn Communicator OFF before removing batteries.

Installing and Removing Communicator Batteries:

! Install a fully charged battery in the battery compartment with the arrow on the battery pointing out as shown in Figure 16. Slide it into the tracks on both sides of the compartment until its catch clicks securely in place.




Figure 16. Installing the battery

! To remove the battery from a Communicator, slide the battery latch open and push the battery in the direction of the large arrow on the battery as shown in Figure 17.




Figure 17. Opening the battery compartment

Charging COM900BP Batteries in the AC420 Battery Charger:

Place up to four COM900BP batteries in the charger to charge at the same time, as shown in Figure 18. A few seconds after each battery is placed in the charger, the red CHARGING light on the panel adjacent to the battery, will indicate the battery charging status. See the CHARGING LIGHT STATUS TABLE for a detailed explanation of what is happening. When a battery is fully charged, the green READY light on the panel adjacent to it will light. **(approximately 4 hours)** It can then be placed back into a Communicator.

CAUTION: Do not remove batteries from the charger until the green READY light is lit, or the charger will reset and the charge cycle will begin again.




Figure 18.

AC420 Battery Charger shown with a properly installed battery

Тор –

Red lights indicate charging status of batteries below the lights, as shown on the Charging Light Status Table below.


Green lights indicate batteries below the lights are fully charged and ready for use. **Headset checker** is used to check headsets for normal operation. Plug the headset cable connector into the headset connector receptacle and speak into the headset microphone. If the headset is operating normally, you will hear your own voice in the earpiece. If the headset is defective, you will hear nothing.

Back -

AC adapter connector is for connecting the AC adapter cable to the charger.

CHARGING LIGHT STATUS TABLE – WITH BATTERY INSERTED			
RED CHARGING LIGHT	WHAT IT MEANS	WHAT TO DO	
OFF	Charger doesn't see the battery	See NOTE	
STEADY ON	Battery is being charged	Wait. Do not remove battery.	
BLINKS: 2 seconds ON; 2 seconds OFF	Battery is being discharged.	Wait. Do not remove battery.	
BLINKS: 2 times quick; 3 seconds OFF	DISCHARGE ERROR	Battery is not discharging properly. See NOTE.	
BLINKS: 3 times quick; 3 seconds OFF	CHARGING ERROR	Battery is not charging properly. See NOTE.	
BLINKS: 4 times quick; 2 seconds OFF	LOW BATTERY ERROR	See NOTE.	
BLINKS: 5 times quick; 2 seconds OFF CHARGING ERROR See NOTE.			
NOTE: Either the battery or the charger has a problem. Mark the battery and retry in a different slot. The battery is faulty it has the same problem in a different slot AND a known-good battery passes in the same slots. The charger circuitry is faulty if a known-good BATTERY fails in the same slots.			

Charging COM900BP batteries in the AC910 Battery Charger:



COM900BP battery charging in the AC910 Battery Charger

Place up to two COM900BP batteries in the charger to charge at the same time. A few seconds after each battery is placed in the charger, the red CHARGING light on the panel adjacent to the battery, will indicate the battery charging status. See the CHARGING LIGHT STATUS TABLE for a detailed explanation of what is happening. When a battery is fully charged, the green READY light on the panel adjacent to it will light. **(approximately 4 hours)** It can then be placed back into a COMMUNICATOR[®].

CAUTION: Do not remove batteries from the charger until the green READY light is lit, or the charger will reset and the charge cycle will begin again.

D. COM930BP COMMUNICATOR®




Figure 20. COM930BP COMMUNICATOR®

The COM930BP COMMUNICATOR[®] consists of a belt-pac transceiver unit and a wireless HS30 Headset, designed to be used with the HME Wireless Drive-Thru Audio System 900. The transceiver unit is worn in a pouch that clips to a belt or waistband at the user's waist.

1. Communicator Controls




Figure 21. Communicator controls


- 1 Power ON and OFF buttons: turns Communicator on and off.
- 2 Volume control buttons: adjust listening level in earpiece.
- 3 Power-on light: lights yellow when Communicator power goes on, and red when the HS30 Headset is also turned on. The power-on light also indicates when the Communicator is transmitting in single or dual-lane mode and when batteries need replacing.
- **4 Button A:** allows two-way communication when pushed and held; when it is released, the user can listen only.
- 5 Button B: must be pushed and held to talk, and released to listen.
- 6 Button C: used to change lanes in dual-lane operations.
- 7 Battery: provides power for the wireless belt-pac Communicator.
- **8 Battery release latch:** slides to release battery for removal, and snaps in place when a battery is inserted to secure battery in Communicator.

Handsfree mode -

To turn Handsfree mode on: With the Communicator OFF, press and hold B+• (vol. up). Then press ON. You will hear "handsfree on."

To turn Handsfree mode off: With the Communicator OFF, press and hold B+– (vol. down). Then press ON. You will hear "handsfree off."


2. Wearing the COM930BP COMMUNICATOR®



Place the belt-pac transceiver unit in its pouch and fasten the velcro flap securely over the front of it as shown in Figure 22. Squeeze open the belt clip on the back of the pouch and slide it over your belt or waist band, either on your right or left side.

Figure 22. Communicator transceiver in pouch

The headset should be worn with the transceiver side (the side opposite the microphone) on the same side as the beltpac transceiver. For best reception, the belt-pac and headset should both be worn in their upright positions. Holding the earpiece, rotate the headset microphone so it is next to your mouth, as shown in Figure 23.





3. Charging the COM930BP Batteries

When a good battery is in the COMMUNICATOR[®] transceiver and the power is on, the yellow light on top of the unit will be lit. When the HS30 Headset also has a good battery in it, and is on, the light on the belt-pac transceiver unit will be red. This light indicates the power is on, and that there is a link between the headset and belt-pac transceivers. It does not indicate how much power is left in the batteries.

CAUTION: To prevent damage, turn Communicator OFF before removing or installing batteries.

Installing and Removing COM930BP Batteries:

As a belt-pac transceiver battery weakens during routine use, you will hear "Low battery" in the earpiece, indicating the battery needs to be replaced. Typical Communicator battery life with normal use is 8 to 9 hours.

Install a fully charged battery in the battery compartment with the arrow on the battery pointing out as shown in Figure 24. Slide it into the tracks on both sides of the compartment until its catch clicks securely in place.




Figure 24. Installing the COM930BP battery

To remove the battery from a COM930BP belt-pac transceiver, slide the battery latch open and push the battery in the direction of the large arrow on the battery as shown in Figure 25.




Figure 25. Opening the COM930BP battery compartment

Installing and Removing HS30 Headset Batteries:

As a HS30 Headset battery weakens during routine use, you will hear a repeating tone in the earpiece, indicating the battery in the transceiver needs to be replaced. Typical HS30 battery life with normal use is 5 to 6 hours.

To install a fully charged battery in the battery HS30 Headset, insert the battery into the battery compartment in the headset transceiver until its catch clicks securely in place, as shown in Figure 26.




Figure 26. HS30 Headset

To remove the battery from a HS30 Headset, push the battery latch open and push the battery from the opposite side of the headset transceiver, in the direction of the arrow on the battery, as shown in Figure 27.

CAUTION: Turn Headset OFF before removing batteries.




Figure 27. HS30 Headset transceiver




Figure 28. AC30 Battery Charger

Place up to four HS30 batteries in the charger to charge at the same time, as shown in Figure 28. A few seconds after each battery is placed in the charger, the red CHARGING light on the panel adjacent to the battery will indicate the battery charging status. See the CHARGING LIGHT STATUS TABLE for a detailed explanation of what is happening. When a battery is fully charged, the green READY light on the panel adjacent to it will light. **(approximately 2.5 hours)** It can then be placed back into a COMMUNICATOR[®].

CAUTION: Do not remove batteries from the charger until the green READY light is lit, or the charger will reset and the charge cycle will begin again.

Charging COM930BP and HS30 Batteries with the AC930 Battery Charger:




Figure 29. AC930 Battery Charger

Place up to two COM930BP batteries and four HS30 batteries in the charger to charge at the same time. A few seconds after each battery is placed in the charger, the red CHARGING light on the panel adjacent to the battery, will indicate the battery charging status. See the CHARGING LIGHT STATUS TABLE for a detailed explanation of what is happening. When a battery is fully charged, the green READY light on the panel adjacent to it will light. **(approximately 4 hours for COM930 batteries and 2.5 hours for HS30 batteries)** It can then be placed back into a COMMUNICATOR[®].

CHARGING LIGHT STATUS TABLE – WITH BATTERY INSERTED				
RED CHARGING LIGHT	WHAT IT MEANS	WHAT TO DO		
OFF	Charger doesn't see the battery	See NOTE		
STEADY ON	Battery is being charged	Wait. Do not remove battery.		
BLINKS: 2 seconds ON; 2 seconds OFF	Battery is being discharged.	Wait. Do not remove battery.		
BLINKS: 2 times quick; 3 seconds OFF	DISCHARGE ERROR	Battery is not discharging properly. See NOTE.		
BLINKS: 3 times quick; 3 seconds OFF	CHARGING ERROR	Battery is not charging properly. See NOTE.		
BLINKS: 4 times quick; 2 seconds OFF	LOW BATTERY ERROR	See NOTE.		
BLINKS: 5 times quick; 2 seconds OFF CHARGING ERROR See NOTE.				
NOTE: Either the battery or the charger has a problem. Mark the battery and retry in a different slot. The battery is faulty if it has the same problem in a different slot AND a known-good battery passes in the same slots. The charger circuitry is faulty if a known-good BATTERY fails in the same slots.				

CAUTION:	Do not remove batteries from the charger until the green READY light is
	lit, or the charger will reset and the charge cycle will begin again.

A.

COM900BP or COM930BP COMMUNICATOR® Operation

In single or dual drive-thru operations, Communicator button "A" is for communication with the customer, and button "B" is for communication with other crew members wearing Communicators. In dual drive-thru operations, the Communicator button "C" is used to change lanes. Button "C" has no function in single drive-thru operations.

To operate the Communicator, use the control buttons shown in Figure 3 as follows. In both single and dual drive-thru operations, Communicator button "A" is for communication with the customer, and button "B" is for communication with other crew members wearing Communicators. In dual drive-thru operations, the "C" button is used to change lanes.

			crew members wearing communicators. In dual drive-third operations, the "C" buttorn's used to change rates.	
	ACTION	RESULT	ACTION	RESULT
Single Drive-Thru Lane	If you are using the Communicator latching feature: Press and release button "A" to latch communication channel open for speaking and listening to customer. The channel will unlatch, ending communication with the customer, if; 1. you press and release button "A" again, or 2. you press button "B" or 3. the customer drives away If you are not using the Communicator latching feature: Press and hold button "A" while speaking and listening to customer. Release when transaction is completed.	Customer hears your voice and you hear customer's voice (two-way conversation). Everyone wearing a Communicator hears the communication.	If you are using the Communicator latching feature: Press and release button "A" to latch communication channel open for speaking and listening to customer. The channel will unlatch, ending communication with the customer, if; 1. you press and release button "A" again, or 2. you press button "B" or 3. the customer drives away If you are not using the Communicator latching feature: Press and hold button "A" while speaking and listening to customer. Release when transaction is completed.	Customer hears your voice and you hear customer's voice (two-way conversation). Everyone wearing a Communicator will hear the conversation.
Full-Duplex Operation	While customer is speaking, press the up ▲ or down ▼ arrow to adjust volume level.	Beep tones of increasing/decreasing frequency are heard in headset as volume level increases/ decreases. Customer's voice becomes louder or softer.	While customer is speaking, press the up ▲ or down ▼ arrow to adjust volume level.	Beep tones of increasing/decreasing loudness are heard in headset as volume increases/ decreases. Customer's voice becomes louder or softer.
	Press and hold button ?B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.	Press and hold button "B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.
Single	Press and hold button ?A" while speaking to customer.	Customer hears your voice. Everyone wearing a Communicator hears the communication.	Press and hold button "A" while speaking to customer.	Customer hears your voice.
Drive-Thru Lane	Release button "A" and listen to customer.	Customer's voice is heard in headsets of everyone wearing a Communicator.	Release button "A" and listen to customer.	Customer's voice is heard in headsets of everyone wearing Communicators.
Half-Duplex	While customer is speaking, press the up \blacktriangle or down \blacktriangledown arrow to adjust volume level.	Beep tones of increasing/decreasing frequency are heard in headset as volume level increases/decreases. Customer's voice becomes louder or softer.	While customer is speaking, press the up \blacktriangle or down \blacktriangledown arrow to adjust volume level.	Beep tones of increasing/decreasing loudness are heard in headset as volume increases/ decreases. Customer's voice becomes louder or softer.
Operation	Press and hold button ?B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.	Press and hold button "B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.
Dual Drive-Thru Lane	If you are using the Communicator latching feature: Press and release button "A" to latch communication Channel 1 open for speaking and listening to customer in Lane 1. The channel will unlatch, ending communication with the customer, if; 1. you press and release button "A" again, or 2. you press button "B," or 3. you press button "C," or 4. the customer drives away If you are not using the Communicator latching feature: Press and hold button "A" while speaking and listening to customer in Lane 1 or 2. Release when transaction is completed. {	Customer hears your voice and you hear customer's voice (two-way conversation). Everyone wearing a Communicator hears the communication. NOTE: When transmitting in Lane 1 operation, the Communicator power light will blink rapidly. When transmitting in Lane 2 operation, the Communicator power light will blink rapidly 4 times, then pause and repeat. Lanes 1 and 2 have different sounding vehicle-present tones.	If you are using the Communicator latching feature: Press and release button "A" to latch communication Channel 1 open for speaking and listening to customer in Lane 1. The channel will unlatch, ending communication with the customer, if; 1. you press and release button "A" again, or 2. you press button "B," or 3. you press button "C," or 4. the customer drives away If you are not using the Communicator latching feature: Press and hold button "A" while speaking and listening to customer in Lane 1 or 2. Release when transaction is completed. {	Customer hears your voice and you hear customer's voice (two-way conversation). Everyone wearing Communicators set to the same channel hears the communication.
Full-Duplex	While customer is speaking, press the up ▲ or down ▼ arrow to adjust volume level.	Beep tones of increasing/decreasing frequency are heard in headset as volume level increases/decreases. Customer's voice becomes louder or softer.	Press button "C" to switch to Lane 2. {	You hear customer's voice from other lane.
Operation	Press button "C" to switch to the other lane. {	You can begin speaking and listening to the customer in the other lane.	While customer is speaking, press the up ▲ or down ▼ arrow to adjust volume level.	Beep tones of increasing/decreasing loudness are heard in headset as volume increases/ decreases. Customer's voice becomes louder or softer.
	Press and hold button ?B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.	Press and hold button "B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.
Dual	Press and hold button ?A" while speaking to customer in Lane 1 or 2. {	Customer hears your voice. Everyone wearing Communicators hears the communication.	Press and hold button "A" while speaking to customer in Lane 1. {	Customer hears your voice. Everyone wearing Communicators hears the communication.
Dual Drive-Thru	Release button and listen to customer.	Customer's voice is heard in headsets of everyone wearing Communicators.	Release button and listen to customer.	Customer's voice is heard in headsets of everyone wearing Communicators.
Lane	While customer is speaking, press the up ▲ or down ▼ arrow to adjust volume level.	Beep tones of increasing/decreasing frequency are heard in headset as volume level increases/ decreases. Customer's voice becomes louder or softer.	While customer is speaking, press the up \blacktriangle or down \blacktriangledown arrow to adjust volume level.	Beep tones of increasing/decreasing loudness are heard in headset as volume increases/decreases. Customer's voice becomes louder or softer.
Half-Duplex Operation	Press button "C" to switch to the other lane. {	You can begin speaking and listening to the customer in the other lane.	Press and hold button "B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.
operation	Press and hold button ?B" to speak to other crew members wearing Communicators. Release to listen.	Other personnel wearing Communicators hear your voice in their headsets.	Press button "C" to switch to Lane. {	You hear customer's voice from other lane.

{ In some dual-lane operations, button "C" is used to switch between Lanes 1 and 2, while button "A" is used to talk to customers in either lane. In some dual-lane operations, button "A" is used to talk to customers in Lane 1, and button "C" is used to talk to customers in Lane 2.

COM900CC COMMUNICATOR® Operation

B. Speed-Team Drive-Thru Operation

Speed team operation is used during high-volume times. Placing the speed-team button on the base station in the ON position will disable the speaker and microphone in the speaker post or menu board, and disable the vehicle-alert tone. An order taker wearing a Communicator relays orders from outside into the store using the "B" channel.

C. Remote Display Operation

One or more R30 Remote Displays may be used with your System 900. Each remote display was set up by the installer to show the amount of time the current car has been at the menu board, speaker post or service window. A remote display shows the time for one location only. It begins counting when the car arrives and stops when the car leaves. The remote displays will only display time. They will not store or record information.

D. Message Repeater Operation and Setup

To record messages on the System 900 internal message repeater, press the MESSAGE REPEATER button IN on the base station and do the following.

	ACTION RESULT	
	Press and release the RECORD MODE button once on the System 900 base station.	The red MESSAGE RECORD light on the System 900 base station will come on.
To record Message #1	Press and hold button 'B' on the COMMUNICATOR [®] and talk into the headset microphone to record a message.	The MESSAGE RECORD light on the System 900 base station will begin blinking.
	Release button "B."	The record function will stop and the MESSAGE RECORD light will go off.
	Press and release the RECORD MODE button twice on the System 900 base station.	The green MESSAGE RECORD light on the System 900 base station will come on.
To record Message #2	Press and hold button 'B' on the Communicator and talk into the headset microphone to record a message.	The MESSAGE RECORD light on the System 900 base station will begin blinking.
	Release button "B."	The record function will stop and the MESSAGE RECORD light will go off.

After a new message has been recorded, or after the base station has lost and regained power, any message to the menu board will always be heard in the Communicator headset the first three times it plays.

To change the message repeater setup, locate and set the S8 and S10 DIP switches at the bottom of the System 900 Base Station audio circuit board. Refer to the S8 AND S10 DIP SWITCH FUNCTIONS tables to the right for S8 and S10 switch functions.

If a System 30 Timer is installed with the System 900, the timer alert output can be used to trigger tones in the headset or to cause a message to be played. Set S8 and/or S10, switch #5 to OFF for an alert tone (triple beep), which will be heard only in headsets, or to ON for recorded messages to be heard through selected speakers and headsets.

If a System 900 is installed without a System 30 Timer, set both S8 and S10 switches #5 to OFF so the message repeater input will be triggered only by vehicle detector signals.

S8 AND S10 DIP SWITCH FUNCTIONS

Refer to Figure 30 on page 23 for DIP switch locations.

S8 — Switch Functions			
Switch	Function		
1	ON - Allow inbound audio while message #1 is playing OFF - DO NOT allow inbound audio while message #1 is playing		
2	ON - Transmit message #1 to Communicators OFF - DO NOT transmit message #1 to Communicators		
3	ON - Send message #1 to outside speaker OFF - DO NOT send message #1 to outside speaker		
4	ON - Send message #1 to ceiling speaker OFF - DO NOT send message #1 to ceiling speaker		
5	ON - Trigger message #1 from alert input OFF - Trigger message #1 from vehicle present input		
6	6 ON - Vehicle present tone is high pitched OFF - Vehicle present tone is low pitched		
7	ON - 3 second delay OFF - No delay		
8	NOT USED		

NOTE: In older equipment, S10 may not be present.

S10 — Switch Functions			
Switch	witch Function		
1	ON - Allow inbound audio while message #2 is playing OFF - DO NOT allow inbound audio while message #2 is playing		
2	ON - Transmit message #2 to Communicators OFF - DO NOT transmit message #2 to Communicators		
3	ON - Send message #2 to outside speaker OFF - DO NOT send message #2 to outside speaker		
4	ON - Send message #2 to ceiling speaker OFF - DO NOT send message #2 to ceiling speaker		
5	ON - Trigger message #2 from alert input OFF - Trigger message #2 from vehicle present input		
6	NOT USED		
7	ON - 3 second delay OFF - No delay		
8	NOT USED		

NOTES:

Message #1 –

Message #2 -

- Communicator.

#2 will be played alternately.

1. Will be triggered by a vehicle present signal if S8 switchs 5 is OFF. The playing message can be cancelled by pressing the "A" button on the Communicator. 2. Will be triggered by an alert signal from the timer if S8 switch 5 is ON. **3.** Will be played to the locations selected on S8 switches 2, 3 and 4. See page 23.

1. Will be triggered by a vehicle present signal if S10 switchs 5 is OFF. The playing message can be cancelled by pressing the "A" button on the

2. Will be triggered by an alert signal from the timer if S10 switch 5 is ON. 3. Will be played to the locations selected on S10 switches 2, 3 and 4. See page 23.

If S8 switch 5 and S10 switch 5 are both sett to ON or OFF, Message #1 and Message

IV. HOW TO CARE FOR THE EQUIPMENT

A. The COMMUNICATOR®

1. Proper Handling of Headset Cables and Connectors HOW TO and HOW NOT TO handle Headset Cables and Connectors

ALWAYS	NEVER
Align the connector key and pins with key and holes in the receptacle when plugging the headset into the Communicator.	Twist headset connector into Communicator receptacle.
F asten cable to pouch with strain relief strap.	Allow cable to be stressed at connector.
C lip the cable to your clothing with the clothing clips.	Allow cable to hang freely.
G rasp the connector to plug in or unplug the headset.	Grasp and pull cable to unplug headset.
U se both hands to remove the headset from your head.	R emove headset with only one hand.
Use both hands to adjust the microphone position.	Adjust microphone position with only one hand.
H and le the heads t cable with care.	P ull, twist, bend or knot the headset cable.
C arry and hang the headset by its metal headband.	C arry or hang the headset by its cable.

2. Cleaning the COMMUNICATOR[®]

The following cleaning procedure is recommended at least once each month.

- ! If the Communicator has a belt and/or pouch, remove it from the pouch. Wash the belt and/or pouch in a washing machine with normal laundry detergent. Dry them in a dryer or hang them up to dry.
- ! Remove the battery from the Communicator.
- ! Clean the Communicator with a damp sponge. Wet the sponge and wring it out so it is damp, not dripping wet. Spray household cleaner on the sponge (NOT DIRECTLY ON THE EQUIPMENT). Clean the Communicator with the sponge, and dry it throughly.
- ! Clean the metal battery contacts on the battery with alcohol on a cotton swab. Wet the tip of the swab with alcohol and squeeze the excess alcohol from it. Wipe each contact with the swab, and be certain all the contacts are dry before installing the batteries.
- Place the battery back in the Communicator and, if there is a pouch, place the Communicator back in the pouch and fasten the strap securely over it.
- ! Clean the headset and cable with a damp sponge sprayed with houshold cleaner. The foam muff on the headset earpiece is easily replaced for sanitary purposes. To order extra foam muffs, call your local HME sales representative.

B. The Battery Charger

Avoid splashing water or grease on the battery charger. Clean the battery charger monthly as follows:

CAUTION: Always unplug the battery charger before cleaning it.

- ! Remove all batteries from the battery charger.
- ! Clean the battery charger case with a damp sponge. Wet the sponge and wring it out so it is damp, not dripping wet. Spray household cleaner on the sponge (NOT DIRECTLY ON THE EQUIPMENT). Clean the battery charger with the sponge, and dry it throughly.
- ! Wet the tip of a cotton swab with rubbing alcohol, and squeeze the excess alcohol from the swab. Wipe the metal contacts inside each battery port with the damp swab. Allow the contacts to dry before placing batteries in the ports.

IN CASE OF PROBLEMS (Refer to the circuit board illustration on page 23.)

V.

TROUBLESHOOTING CHECKLIST			
Problem	Probable Cause	Solution	
No sound in headset	Power is off at base station.	Check circuit breaker for building.	
when you press COMMUNICATOR [®] button "A" and speak into headset microphone.	Power supply in base station is not working.	Check power supply indicator lights on base station. If any light is not lit, be certain AC power adapter is plugged into AC electrical outlet, and connected to J4 connector on audio circuit board in base station.	
	Communicator not turned on.	Turn Communicator on by pushing ON/OFF button for 1 second. Be certain light goes on.	
	Volume not set correctly.	Push volume-control buttons to adjust volume.	
	Headset connector not plugged in properly. (This applies only to COM900BP and COM900CC.)	Plug headset connector firmly into Communicator receptacle.	
	Headset defective.	Replace with another headset.	
	Low or dead battery.	Check ON/POWER light. If not lit, replace battery.	
	Communicator failed.	Use another Communicator. Call HME. *	
COM930	HS30 Headset not turned on.	Press On/Off switch to turn headset on.	
Only	HS30 Headset battery is low or dead.	Change battery.	
Communicator channel	Communicator not turned ON.	Turn Communicator on.	
"A" or "B" functions not working.	Dead or weak battery.	Replace battery.	
working.	Communicator or base station failure. Channel "A" or "B" light on base station does not light when Communicator button "A" or "B" is pressed.	Use another Communicator. Call HME. *	
"C" button does not switch between channels in a dual-lane drive-thru.	Set for dual-lane operation.	With power off, press and hold the "C" button while turning the Communicator on.	
Outbound sound too low.	Outbound volume set too low for environment.	Turn outside speaker volume control (R128 in base station) clockwise with small standard (slotted) screwdriver until level is satisfactory.	
No outbound sound; customer cannot hear	System may be set for speed-team operation.	Be certain SPEED TEAM button on base station is out (OFF).	
anything.	Loose wires on base station circuit board.	Check all wire connections to J2 on base station switcher board.	

* For assistance, call HME at 1-800-848-4468, or Fax 858-552-0172.

Problem	Probable Cause	Solution		
No inbound sound from customer (in half-duplex operation)	Latching feature may be on.	See instructions on page 18 to turn off latching feature.		
	System may be set for speed-team operation. See pages 1 and 19.	Be certain SPEED TEAM button on base station is out (OFF).		
	Base station may be set for wrong drive- thru mode (full or half-duplex).	Check S6 switch on base station circuit board. Switch #1 should be ON for full-duplex OFF for half-duplex		
Personnel hear static only in headsets.	Transmitter antenna connection on base station is loose.	Tighten transmitter antenna connection. (the antenna on top, left of base station.)		
	No power to base station.	Check base station power adapter connections.		
	Circuit board defective.	Call HME. *		
	Interference from nearby equipment.	Person wearing Communicator should move to different location.		
COM930 Only	Belt-pac and/or headset not properly worn.	Be certain belt-pac is securely clipped onto belt or waistband, close to body, and both belt-pac and headset are in upright positions.		
Personnel hear customer in headsets or ceiling speaker, but cannot hear	Receiver antenna connection on base station is loose.	Tighten receiver antenna connection. (the antenna on top, right of base station.)		
each other.	Status lights are not lit. Circuit board is defective.	Call HME. *		
	Defective COMMUNICATOR® or headset.	Call HME. *		
No tone or sound in headset or ceiling speaker when vehicle	Power interruption has caused unbalanced detecting circuit.	When no vehicle is in the drive-thru lane, press vehicle detector override switch on base station to RESET position.		
drives into drive-thru lane.	System may be set for speed-team operation. See pages 1 and 19.	Be certain SPEED TEAM button on base station is out (OFF).		
	Connector may be loose.	Check all connectors. Call HME. *		
Personnel cannot hear outside customers in	Loose wires on base station circuit board connector.	Be certain wires are securely connected in base station.		
headset or ceiling speaker.	System may be set for speed-team operation.	Be certain SPEED TEAM button on base station is out (OFF).		
	Outside speaker or audio circuit board has failed.	Call HME. *		
Communicator has	Low battery.	Replace battery.		
intermittent sound.	Defective headset cable. (This applies only to COM900BP and COM900CC.)	Use another headset. Call HME. *		
Headset does not become silent after	OVERRIDE/NORMAL/RESET switch on base station is in the OVERRIDE position.	Place switch in the NORMAL position.		
customer has driven away.	Vehicle detector is locked up.	Press OVERRIDE/RESET switch twice.		
Battery charger not working.	Charger not plugged in.	Plug in battery charger. If still not working, call HME. *		
Can not record message.	Message repeater not turned on.	Turn message repeater on.		
Message will not play.		Message will not play.		

* For assistance, call HME at 1-800-848-4468, or Fax 858-552-0172.




Figure 30.

Base station circuit boards

- A Transmitter antenna connector
- B Receiver antenna connector
- C Wired backup system switch S2
- D DM2 select switch S1
- E Power and ceiling speaker connector J2
- F Record message switch S2
- G Message repeater ON/OFF switch S3
- H Speed team switch S5
- Vehicle detector override switch S7
- J Frequency select switch S1
- K Ceiling speaker volume controls R142, R294, R298, R299, R300
- L Outside speaker volume control R128
- M Power supply LED DS3

- N VAA level control R113
- O Inbound volume control R43
- P Automatic test equipment connector J1
- Q Message record LED DS7
- R Receiver LED DS1
- S Channel "A" and "B" LEDs DS4, DS5
- T Vehicle present LED DS6
- U Channel "A" and "B" sidetone level controls R77, R60
- V Message volume controls R292, R293
- W Vehicle present tone volume control R160
- X System configuration switches S4, S6, S8, S9, S10
- Y Base-to-base connector (for dual drive-thru operations) J9
- Z Remote display connector J15

VI. SPECIFICATIONS

Base Station

1.	Voltage input	16VAC ±2.5V	
2.	AC current input		350mA nominal, 1.4A maximum
3.	Audio distortion		<5% maximum level
4.	Outside speaker outp		3 watts RMS into 8 ohms
5.	Ceiling speaker powe	r	3 watts RMS into 8 ohms
6.	Message repeater		Message duration - 16 seconds
7.	Controls/Switches		2-position vehicle detector switch
			(Normal - Override/Reset)
			2-position "Speed Team" ON/OFF switch
			2-position "Message Repeater" ON/OFF switch
			1-position "Record" switch
			4-position RS485 bias/term switch
			Outside speaker volume control
			Outside speaker Hi-Lo volume jumper
			Vehicle present tone level control
			"A" sidetone
			"B" sidetone
			Inbound volume control
			VAA level control
			Ceiling speaker volume control
			Vehicle present tone volume control
			(3) 8-position DIP switches
			4-position frequency select switch
			Wireless/wired system select switch
0			Horn speaker/DM1 select switch
8.	TX/RX Frequency	FCC Part 90	
9. 10	Dimensions		8.2"H x 14.2"W x 3.5"D (208mm x 361mm x 89mm)
10.	Weight		5.5 lbs (2.49kg) maximum
COM9		R®	

1.	Battery (NiMH)	8 hours
2.	RF Frequency	Receive — FCC Part 90
		Transmit — FCC Part 90
3.	Dimensions	3 d "H x 4 c "W x 1½"D (86mm x 114mm x 38mm)
4.	Weight	12 ounces (3.40kg) — including battery
5.	Controls	Buttons "A," "B" and "C"
		Power control
		Volume control
6.	Indicator	Red LED
		Solid when receiving only.
		Blinking when transmitter is activated, or
		on secondary lane for dual-lane systems
7.	Connector	LT

COM900BP COMMUNICATOR®

1. 2.	Battery (NiCd) RF Frequency	8-10 hours Receive — FCC Part 90 Transmit — FCC Part 90
3. 4.	Weight Controls	11 ounces (3.12kg) — including battery Buttons "A," "B" and "C" Power On/Off button
5.	Indicator	Volume control buttons Red LED Solid when receiving only Blinking when transmitter is activated
6.	Connector	5-pin DIN
COM93	30BP COMMUNICATOR®	
1.	Belt-pac Battery (NiCd) Headset Battery (NiMH)	8-10 hours 5-6 hours
2.	RF Frequency	Receive — FCC Part 90

Kit frieduency
 Kit frieduency
 Transmit — FCC Part 90
 Weight
 Controls
 Buttons "A," "B" and "C"
 Power On/Off button
 Volume control buttons
 Indicator
 Red LED
 Solid when receiving only
 Blinking when transmitter is activated

AC30 Battery Charger (for HS30 NiMH batteries)

1.	Voltage input:	16.5VAC
2.	Number of charge ports:	4
3.	Charge time:	2-3 hours
4.	Dimensions:	7.5"L x 4"W x 2¾"D (191mm x 102mm x 70mm)
5.	Weight:	20.22 oz (.573Kg)
6.	Indicators:	Battery-charging (red) LEDs, 4 ea
		Battery-ready (green) LEDs, 4 ea

AC420 Battery Charger (for COM900BP and COM930BP NiCd batteries)

2.Number of charge ports:43.Charge time:44.Dimensions:85.Weight:26.Indicators:8	16.5VAC 4 4-8 hours 3"L x 12"W x 3.5"D (203mm x 305mm x 89mm) 24 oz (.680Kg) - not including AC adapter Battery-charging (red) LEDs, 4 ea Battery-ready (green) LEDs, 4 ea
---	--

AC900 Battery Charger (for COM900CC NiMH batteries)

1.	Voltage input:	16.5VAC
2.	Number of charge ports:	4
3.	Charge time:	2 hours
4.	Dimensions:	7.5"L x 4"W x 3 ⁷ / ₈ D (191mm x 102mm x 78mm)
5.	Weight:	23.04 oz (.653Kg)
6.	Indicators:	Battery-charging (red) LEDs, 4 ea
		Battery-ready (green) LEDs, 4 ea

AC910 Battery Charger (for COM900BP NiCd and COM900CC NiMH batteries)

1.	Voltage input:	16.5VAC
2.	Number of charge ports:	4 for COM900CC NiMH batteries
		2 for COM900BP NiCd batteries
3.	Charge time:	2 hours for COM900CC NiMH batteries
		4-8 hours for COM900BP NiCd batteries
4.	Dimensions:	7.5"L x 7.5"W x 3 ⁷ / ₈ D (191mm x 191mm x 78mm)
5.	Weight:	31.94 oz (.906Kg)
6.	Indicators:	Battery-charging (red) LEDs, 4 ea
		Battery-ready (green) LEDs, 4 ea

AC930 Battery Charger (for COM930BP NiCd and HS30 NiMH batteries)

1.	Voltage input:	16.5VAC
2.	Number of charge ports:	4 for COM930 headset NiMH batteries
		2 for COM900 belt-pac NiCd batteries
3.	Charge time:	2-3 hours for COM930 headset NiMH batteries
		4-8 hours for COM900BP belt-pac NiCd batteries
4.	Dimensions:	7.5"L x 7.5"W x 3 ⁷ / ₈ D (191mm x 191mm x 78mm)
5.	Weight:	29.10 oz (.825Kg)
6.	Indicators:	Battery-charging (red) LEDs, 4 ea
		Battery-ready (green) LEDs, 4 ea

VII. ACCESSORIES AND OPTIONAL EQUIPMENT

The following optional equipment is available for use with your System 900. To order any of these products, call the HME Sales Department at (858) 535-6060.

Equipment	Model Number
COMMUNICATOR®	COM900BP
COMMUNICATOR®	COM900CC
COMMUNICATOR®	COM930BP
Battery (NiCd) for COM900 or COM930BP COMMUNICATOR®	BAT400
Battery (NiMH) for HS30	BAT30
Battery (NiMH) for COM900CC	BAT900
Headset for COM900BP	HS9-90
Headset for COM900CC	HS9LT
Headset for COM930BP	HS30
Headset Earmuff	no model number
Earpiece/Microphone	HS4
Ultrasonic Vehicle Detector	DU3
Vehicle Detector Board	VDB101A
Vehicle Detector Loop (underground)	VDL100
Message Repeater	MR300
Remote Display	R30
Ceiling Speaker	MM100
Low-Profile Speaker with Volume Adjustment	MM2500
Microphone	DM1
Speaker	SP2000A
Mode Switch (dual lane)	MS1000

VIII. FCC NOTICE

HME wireless radio frequency systems are type-accepted in the United States under Part 90 of the Federal Communications Commission (FCC) Code of Federal Regulations, and type-approved in Canada by Industry and Science Canada. Because licensing depends on the system's application, it is the user's responsibility to apply for a license from the FCC in the U.S. and its possessions, or from Industry and Science Canada in Canada and its territories. Licensing requirements vary from country to country. Contact your local licensing agency for specific requirements.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communication. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by HM Electronics, Inc. could void the users authority to operate this equipment.